


Service Manual

SIDE MOUNT PIZZA PREP TABLES

MODEL : EPPR1

EPPR2

EPPR3



EVEREST
REFRIGERATION

201 W.Artesia Blvd.

Compton, CA 90220

Tel.(310) 323-6586 (800)444-6285

Fax.(310) 323-7524 (310)761-1127

www.EVERESTref.com

TABLE OF CONTENTS



1. SAFETY PRECAUTIONS	3
2. MAINTENANCE	
2.1 Interior and Exterior Cleaning	4-5
3. REFRIGERATION CYCLE	
3.1. Refrigeration Cycle	6
4. WHERE TO INSTALL	7
5. SPECIFICATIONS	
5.1 Dimension & Room Section	8
5.2 Electricity Per Models	9
6. WIRING DIAGRAMS	10
7. DISASSEMBLING MACHINE ROOM FOR SERVICE	
7.1 Disassembling & Taking out the cover	11-12
7.3 Disassembling the rear plate	12
8. ELECTRONIC CONTROLLER	
8.1 Display (User Interface)	13
8.2 Display LED Symbols	13
8.3 Button Symbols	13
8.4 Checking and Changing operating values	13
8.5 Manual Defrost ON/OFF	13
8.6 Parameter setting	13
8.7 Parameter setting ("C"parameter)	14
8.8 Table of Alarms and Signals	14
8.9 Table of Easy Parameters	15-16
9. SERVICE INSTRUCTIONS	
9.1 Control Box Assembly	
9.1.1 How to Disassemble Control Box Assembly	17-18
9.1.2 Electronic Controller	19
9.1.3 How to Remove Electronic Controller	20
9.1.4 Power Cord Set	20

TABLE OF CONTENTS



9.2 Condensing Unit Assembly	
9.2.1 How to Remove Condensing Unit Assembly	21
9.2.2 Components of Condensing Unit Assembly (Normal System)	22
9.2.3 How to Remove Compressor	23
9.2.4 Compressor Technical Data	24
9.2.5 Compressor Technical Data	25
9.2.6 Compressor Troubleshooting	26–27
9.2.7 Condenser Fan Motor Assembly	28
9.2.8 Replacement of Condenser and Filter Drier	29
9.2.9 Replacing Service Valve	29
9.3 Evaporator	
9.3.1 Evaporator FAN Motor	30
9.3.2 Checking for Evaporator Leaks	30
9.4 How to Check Heater	31
9.5 Door	
9.5.1 How to Remove Door Assembly	32–34
9.5.2 Door Tension Adjustment	35–36
9.5.3 Door Handle	37
9.5.4 Door Gasket	38
10. DIAGNOSTIC	
10.1 SERVICE DIAGNOSTIC CHART	39–41

1. SAFETY PRECAUTIONS.

1. Safety Precautions

The power cable should be unplugged before replacing or repairing any electrical parts.

When replacing electrical parts, rated parts should be used.

- The procedure also requires that specifications such as model, rated voltage, rated current and operating temperature are precisely matched.

Use appropriate tools when replacing parts.

Coupling harnesses and lead wirings should be connected without exposing the core strip.

When servicing the unit, dust or other impurities must not come in contact with the wiring assembly located in the housing.

Check for moisture marks on all electrical parts.

- If moisture marks exist, it is recommended that you replace the part/s or take measures in preventing further moisture exposure.

Check assembly state of parts after service.

- Ensure that it matches the assembly state before service.

If operation seems unstable, it is recommended that you change the unit's location.

- The unit must be installed in a temperature regulated room with low humidity and away from heat sources or combustible products. Allow sufficient room for ventilation.

Determine whether unit should be grounded.

- It should be grounded if you determine that moisture or water exposure may cause electrical leakage.

High energy consumption products such as heaters should have exclusive outlets.

Avoid having several power plugs in one outlet.

2. MAINTENANCE

2.1 Interior and Exterior Cleaning

Use ONLY stainless steel cleaners when cleaning the interior and exterior of the cabinet.

WARNING • The unit's exterior stainless steel surface is made of 430 series material which will rust if exposed to non-stainless steel cleaners.

CAUTION • Never use steel wool, strong acids, or abrasive cleaners when cleaning the exterior or interior of the unit.
• Acidic products or products containing vinegar must be stored in sealed containers to prevent acid damage to the interior of the cabinet and the evaporator coil.

2.2 CONDENSER CLEANING

IMPORTANT : Use this procedure to clean the condenser at least once a month.

A dirty condenser coil restricts airflow, resulting in excessively high operating temperatures. This reduces the unit's efficiency and shortens component life.

WARNING • Disconnect the electrical power to the unit before cleaning the condenser.
• The condenser fan blade is sharp. Be careful when cleaning.

CAUTION • If you are cleaning the condenser fan blades, cover the fan motor to prevent water damage.

2. MAINTENANCE

1. Clean the air filter.
2. Clean the outside of the condenser with a soft brush or vacuum brush. Clean from top to bottom, not from side to side. Shine a flashlight through the condenser to check for dirt between the fins. If dirt remains:
 - a. Blow compressed air through the condenser coil.
 - b. Use a commercial condenser coil cleaner. Follow the directions and any precautions supplied with the cleaner.
3. Repeat 2 until all dirt is removed.
4. Carefully wipe off the fan blade and motor with a soft cloth. Do not bend the fan blades. If the fan blades are excessively dirty, wash with warm, soapy water and rinse thoroughly.

3. REFRIGERATION CYCLE

3.1. Refrigeration Cycle




Fig 3-1

4. WHERE TO INSTALL

1. The unit should be installed on a level surface.

CAUTION : Temperature and drainage issues will occur if the product is tilted slightly forward or backward. If necessary, adjust the height of the caster(s) by using washers to ensure that the unit is leveled.

2. The unit is designed for indoor and commercial use. Outdoor installation will cause a decrease in performance and significant damage if exposed to sunlight and rain.
3. Do not install the unit under a shelf or any location where a foreign object could fall into the condensing unit area or the top of the cabinet.
4. Select a location away from heat and moisture generating equipment such as a stove, oven, dish washer, etc.
5. Minimum Clearance Requirements [Figure 4-1]
Top : 20" above the condensing unit
Back & Side : 6" at the back and each side
6. Do not tilt the unit during delivery and installation. Compressor oil might run into condensing coil through high pressure pipe, which will cause pressure problems due to a clog in the capillary tube.

CAUTION : If minimum clearances are not maintained, cooling capacity will be reduced. This may lead to product loss or premature component failure.

7. The four casters supplied by the manufacturer must be installed. Failure to do so will cause a malfunction in the condensate pan heater located underneath the cabinet.
8. Ambient Temperature for Condenser
Minimum : 50 °F
Maximum : 90 °F





Fig 4-1

5. SPECIFICATIONS

5.1 Dimension & Room Section




5. SPECIFICATIONS

5.2 Electricity Per Models


MODEL		BC180PR-2RR0S-E	BC240PR-3RRRS-E
Product		Horizontal Sandwich	
Dimensions (W x D x H)	Exterior	1800 x 845 x 1030	2370 x 845 x 1030
Doors		2	3
Shelves		4	6
Capacity(ℓ)		557	733
Insulation Blowing Agent		R141b	
Refrigerations Unit	Compressor	1/3	1/3+
	Refrigerant	R-134A	R-134A
	Charge	280g	340g
	Capillary tube	1.2Øx1650	1.2Øx1550
	Condenser	3/8x4Rx10Sx180L	3/8x4Rx10Sx180L
	Evaporator	3/8x4Rx7Sx410L	3/8x4Rx7Sx510L
Power Voltage		240 V ~ 50Hz	
Rated Current		2.9 (A)	3.05 (A)
PCB Controller	PZBUSNPOE1K	1	1
	PZBUC0H011K		
Evaporator fan motor		220V, 50-60Hz, 12W	
Condenser fan motor		220V, 50-60Hz, 27W	
Lighting		Lamp, 240V 25W	
Relay	Spec	N/A	
	Q 'TY		
Power Supply Cord Set		H05VV-F , 3x1.0mm ² , 250V~ , 10A	
Solenoid Valve 3-WAY	Spec	Electrical: 220V ±15% , Outlet Tube : Ø 3.97 Power Consumption: 7W, Inlet Tube: Ø 6.35	
	Q 'TY	N/A	
Service Valve	1/4"	2	
	3/8"	N/A	

Table 5-1

6. WIRING DIAGRAMS



EPPR2




EPPR3

7. Disassembling Machine Room for Service

For controller operation, cleaning or other A/S related service, first remove the cover of the machine room as seen in Fig 7-10. For the removal of the machine room's rear and side plates, please refer to 7.2 and 7.3.

7.1 Removal and Disassembly of the Cover

The machine room cover is held by two hinges (Fig 7-2) and a magnet (Fig 7-3). Swing the cover along the direction of the arrow (Fig 7-1). To completely remove the cover, lift it up vertically to detach it from the body frame (Fig 7-2).



7.2 Side Plate Disassembly

To remove the side plate, it is necessary to loosen 6 side screws and 1 rear screw. Note that the top corner of is inserted inside the plate. Pull it out to detach.

7. Disassembling Machine Room for Service





Fig 7-4



Detail A




Fig 7-5




Fig 7-6

7.3 Rear Plate Disassembly

To remove the rear plate, first remove the side plate as shown in Fig 7.2 and loosen 3 "a" screws marked in Fig 7-4. The rear plate detaches when the last bolt inside the machine room is unscrewed.





Fig 7-7



Detail B

8. ELECTRONIC CONTROLLER

How to operate the controller



8.1 Display (User Interface)

The console is a typical 3-button CAREL display which regularly shows values from the operating sensor and alternately represents temperature and alarm codes once an alarm is generated.

8.2 LED Display Symbols (Fig 8-1)

- ①, : ON if compressor output is ON.
- ②, : ON if evaporator fan is in operation.
- ③, : ON if manual and electric defrost is in operation.
- ④, : ON if temperature is displayed (-99 ~ 99℃).
- ⑤, : Alarm in progress.




Fig 8-1

8.3 Button Symbols (Fig 8-2)

- ①,: Output ON/OFF if pressed for over 3 seconds.
- ②,: Changes operating values if pressed for 1 second.
Access parameter settings if pressed for over 3 seconds.
- ③,: Manual defrost ON/OFF if pressed for over 3 seconds.




Fig 8-2

8.4 Checking and Changing Operating Values

To check operating values, press  button for 1 second.
Preset values flickers.
Change the values by using  buttons and press  button.

8.5 Manual Defrost ON/OFF

Defrost ON: press  Down button for 3 seconds and longer.
Defrost OFF: press  Down button for 3 seconds and longer while on defrost.

8.6 Parameter Settings

Press  key for over 3 seconds and it displays parameters and then displays [PS].
Move to the desired parameter code by using  Up or  Down keys and press .
Change a selected parameter by using  Up or  Down keys.
Press  key to save the changed values.
To exit the menu, press  key over 3 seconds.
(The present temperature is displayed)

8. ELECTRONIC CONTROLLER

8.7 Parameter Settings (“C” parameter)

Hold down  key for over 3 seconds so it displays parameters and then [PS].

Press  again so it displays “00.” Enter “22” for the password and press .

The first parameter “/2” is displayed.

Move to the desired parameter code by using  Up or  Down keys and press .

Change a selected parameter by using  Up or  Down keys.

Press  key to save the changed values. .

To exit the menu, hold down the  key over 3 seconds.

(The present temperature will be displayed)

8.8 Table of Alarms and Signals.

When an alarm is activated, the display shows the corresponding message that alternately flashes with the temperature. If fitted and enabled, the buzzer and the alarm relay are also activated.

All the alarms have automatic reset (that is, they stop when the cause of alarm is no longer present). The exception to this is alarm “CHt” which has a manual reset.

Alarm Code	Buzzer And Alarm Relay	LED	Alarm Description
E0	active	ON	probe 1 error = control
E1	not active	ON	probe 2 error = defrost
LO	active	ON	low temperature alarm
HI	active	ON	high temperature alarm
EE	not active	ON	unit parameter error
	not active	OFF	defrost running

Table 8-1

8. ELECTRONIC CONTROLLER

8.9 Table of easy parameters

NOTES : "F" means that the parameters can be accessed without a password.
"C" means that the parameters are protected by a password.

Name	Description	Type " A "		Type " B "	
		Def	Vis.	Def	Vis.
Pw	Password	22	F	22	F
/2	/2 Probe measurement stability	15	C	15	C
/4	/4 Select probe display	1	C	1	C
/5	/5 Select u.d.m. probe °C / °F	1	C	1	C
/6	/6 Disable decimal point	1	C	1	C
/C1	/C1 Probe 1 offset	0	F	0	F
/C2	/C2 Probe 2 offset	0	F	0	F
/C3	/C3 Probe 3 offset	0	C	0	C
St	Set point	35	S	-4	S
rd	rd Control differential	4	F	4	F

8. ELECTRONIC CONTROLLER

r1	r1 Minimum set point value	1	C	-23	C
r2	r2 Maximum set point value	12	C	12	C
r3	r3 Select direct / reverse operation	0	C	0	C
r4	r4 Night-time set point delta	3	C	3	C
c0	c0 Compressor and fan start delay on power-up	1	C	1	C
c1	c1 Minimum time between consecutive compressor starts	0	C	0	C
c2	c2 Minimum compressor off time	0	C	0	C
c3	c3 Minimum compressor on time	0	C	0	C
c4	c4 Duty setting	0	C	0	C
cc	cc Continuous cycle duration	4	C	4	C
c6	c6 Temperature alarm bypass after continuous cycle	2	C	2	C
d0	d0 Type of Defrost	0	C	2	C
dl	dl Interval between defrost	6	F	6	F
dt	dt End defrost temperature set point	16	C	16	C
dP	dP Maximum defrost duration ALARM_ED	20	F	20	F
d4	d4 Defrost when switching the instrument on	0	C	0	C
d5	d5 Defrost delay on power-up	0	C	0	C
d6	d6 Freeze control temperature display during defrost	0	C	0	C
dd	dd Dripping time	2	C	2	C
d8	d8 Alarm bypass time after defrost	1	C	1	C
d9	d9 Defrost priority over compressor protectors	0	C	0	C
d/	d/ Defrost probe reading	-	F	-	F
dC	dC time base	0	C	0	C
A0	A0 Alarm and fan temperature differential	0	C	0	C
AL	AL Absolute/relative temperature for low temp. alarm	-50	C	-50	C
AH	AH Absolute/relative temperature for high temp. alarm	50	C	50	C
Ad	Ad Temperature alarm delay	0	C	0	C
A4	A4 3rd input configuration	0	C	0	C
A7	A7 Digital input alarm delay	0	C	0	C
A8	A8 Enable alarm ED(end defrost by timeout)	0	C	0	C
Ac	Ac Set point dirty condenser alarm	70	C	70	C
AE	AE Dirty condenser alarm differential temperature	5	C	5	C
Acd	Acd Dirty condensor alarm delay	0	C	0	C
F0	F0 Enable evaporator fan control	0	C	0	C
F1	F1 Evaporator fan control set point	5	C	5	C
F2	F2 Stop evaporator fan if compressor off	0	C	0	C
F3	F3 Evaporator fan status during defrost	1	C	1	C
Fd	Fd Post-dripping time	1	C	5	C
H0	H0 Serial address	1	C	1	C
H1	H1 AUX output configuration	0	C	0	C
H2	H2 Enable keypad	1	C	1	C
H5	H5 Detect changed parameters	1	C	1	C
EZY	Rapid parameter set selection	0	C	0	C

Table 8-3

9. SERVICE INSTRUCTIONS

9.1 Control Box Assembly

Warning : Make sure that the power is disconnected before servicing the unit. Allow for sufficient working area to ensure your safety and the safety of the unit. Please note that grounding is necessary when reinstalling the unit after service.

9.1.1 How to Disassemble the Control Box Assembly

Remove the machine room cover to gain access to the control box. (Fig 7-2).

Unscrew the 2 bolts securing the condensing unit. Pull the unit out until there is sufficient room for service (Fig 9-2).




Fig 9-1






Fig 9-2




Detail A

To access the control box interior, unscrew the 4 bolts located on the top cover of the housing. To replace the entire control box assembly, remove the main controller connector and sensor connector. Unbolt the screws fixing the control box housing to the condenser coil in the machine compartment. Also unbolt the screws fixing the grounding wire and power cord set.

9. SERVICE INSTRUCTIONS



Pic 9-1



Pic 9-2

9. SERVICE INSTRUCTIONS

9.1.2 Electronic Controller

Model	PZBUC0H0E1K
Power Supply (*)	230 Vac +10 /-15% 50/60 Hz;
Rated Power	3.5 VA
Inputs (*)	NTC probe
Relay Outputs (*)	16A relay UL: 12 A resistive 5 FLA, 30 LRA 250 Vac 30000 cycles EN60730-1: 12(2)A or 10(4)A (N.O. only) 250 Vac
Type Of Probe (*)	Std CAREL NTC 10 K Ω at 25 °C
Power supply/ relay output connector (*)	screw terminals pitch 5mm for cables with cross-sect. from 0.5 mm ² to 1.5 mm ² ; 12 A max;.
Probe connector(*)	screw terminals: – 2-pin pitch 5mm for models with 1 probe (cable cross-section from 0.5 mm ² to 1.5 mm ²); 12 A max;
Assembly (*)	using screws from the front
Display	LED display, 2 digits plus sign, decimal point and compressor icon
Keypad	3 buttons with membrane
Operating conditions	-10T50 °C – humidity <90% rH non-condensing
Storage conditions	-20T70 °C – humidity <90% rH non-condensing
Range of measurement	-50T90 °C (-58T194 °F) – resolution 0.1 °C/°F
Front panel index of protection	panel installation with IP65 gasket
Case	plastic terminal, 81x36x38 mm
Classification according to protection against electric shock	Class II when suitably integrated
Environmental pollution	II
PTI of the insulating material	250 V
Period of stress across the insulating parts	long
Category of resistance to heat and fire	category D (UL94 – V0)
Immunity against voltage surges	category 1
Type of action and disconnection	micro-disconnection 1C
No. of relay automatic operating cycles (*)	EN60730-1:100,000 operations UL:30,000 operations (250 Vac)
Software class and structure	Class A
Cleaning the instrument	Only use neutral detergents and water.
Cable max. length	serial: 1 km, probes: 30 m, relay: 10 m

Table 9-1

9. SERVICE INSTRUCTIONS

9.1.3 How to Remove Electronic Controller




Fig 9-3




Fig 9-4




Fig 9-5

Remove the controller cover by using a blunt / flat tool as shown in the above figure (Fig 9-3). Use a (+) screwdriver to loosen the two screws on the controller until you get a gap on the stopper (Fig 9-4). Pull out the controller from the control box.

Reassemble in reverse order. (Fig 9-5)

9.1.4 Power Cord Set

When replacing the power cord set, check to ensure it is rated. Unrated components may cause a fire, fault or electrical shock. To re-wire the power cord set, twist the same colored wires together (natural + natural, live + live). Tighten it using a close end connector (Fig 9-6).




Fig 9-6

When selecting a new power cord set, refer to Table 5. Currently, new sets should have equal or higher capacity. Ensure that the replacement is suitable to avoid electrical-related accidents.



9. SERVICE INSTRUCTIONS

9.2 Condensing Unit Assembly

Warning : Make sure the power is disconnected before servicing.
Wait until the condenser fan is stopped completely.

9.2.1 How to Remove the Condensing Unit Assembly





Fig 9-7

1. To remove the condensing unit, detach the machine room cover. Refer to Fig 7.1 and Fig 9.1.1.
2. Remove two screws on the unit base (**Detail A**).
3. Remove two screws on the clamp holding the suction pipe in place (**Detail A**).
4. To disassemble the suction pipe assembly, use a spanner to loosen the high/low pressure flare nuts connected to the service valve (**Detail A**).
5. Detach the Condensing Unit Connector, Main Controller Connector, and Sensor Connector.
6. Loosen the screws and the grounding screw(s) coupled in the inner wall of the machine room.
7. Since the unit base is coupled with the rail, set it down and pull it out to detach. (**Detail A**).



9. SERVICE INSTRUCTIONS



Condensing Unit
Connector

Pic 9-3



Pic 9-4

Ground

9.2.2 Components of Condensing Unit Assembly (Normal System)






Fig 9-8

9.SERVICE INSTRUCTIONS

9.2.3 How to Remove Compressor

1. Open compressor's electrical components housing and remove the lead wire coupled into the power motor and other parts. This is connected to the relay and overload protector. (Fig 9-10)
2. Before removing the compressor, check the machine for remaining refrigerant.
3. To remove remaining refrigerant and balance internal pressure, cut the process tube.
4. Remove discharge tube and suction tube by using a gas burner.
5. Loosen the nuts on the compressor. (Fig 9-11)
6. Lift up the compressor to detach.



9.SERVICE INSTRUCTIONS

9.2.4 Compressor Technical Data

Model				FFI10-HAKW [1/3HP]				
Type				Hermetic reciprocating compressor				
Refrigerant				R-134a				
Nominal voltage and frequency				220-230 / 50-60		[V / Hz]		
Application type				Low-Medium Back Pressure				
Evaporating temperature range				-35[°C] to -5[°C]				
Motor type				RSIR/CSIR				
Starting torque				LST – Low Starting Torque				
Expantion device				Capillary tube				
Maximum condensing pressures								
Operating (gauge)				16.2 [kgf/cm²]		(230 psig)		
Peak (gauge)				20.6[kgf/cm²]		(293 psig)		
Maximum winding temperature				130		[°C]		
Performance								
Cooling capacity			Power consumption	Current consumption	Gas flow rate	EFFICIENCY RATE		
[Btu/h]	[kcal/h]	[W]	[W]	[A]	[kg/h]	[Btu/Wh]	[Btu/Wh]	[W/W]
850	214	249	191	1.73	4.83	4.45	1.12	1.3
Start capacitor				53-64(230)		[μF(VAC minimum)]		
Motor protection (external)								
Code				4TM757KFBYY-53				
Opening Temperature				105°C (221°F)				
Closing Temperature				61°C (141,8°F)				
Triping Current at 25°C (77°F)				9,8 A				
Reaction Time				5.0s – 15.0s				
Current Relay								
Pick Up Current (A)				6,8				
Drop-Out Current (A)				5,2				
EXTERNAL CHARACTERISTICS								
SUCTION				6.5		[mm]		
DISCHARGE				6.5		[mm]		
PROCESS				6.5		[mm]		

[Compressor : FFI10-HAKW]

Table 9-2

9.SERVICE INSTRUCTIONS

9.2.5 Compressor Technical Data

Model				FFI 12HBKW [1/3+HP]				
Type				Hermetic reciprocating compressor				
Refrigerant				R-134a				
Nominal voltage and frequency				220-230 / 50-60		[V / Hz]		
Application type				Low-Medium high Back Pressure				
Evaporating temperature range				-35[°C] to -5[°C]				
Motor type				RSIR/CSIR				
Starting torque				LST – Low Starting Torque				
Expantion device				Capillary tube				
Maximum condensing pressures								
Operating (gauge)				16.2 [kgf/cm²]		(230 psig)		
Peak (gauge)				20.6[kgf/cm²]		(293 psig)		
Maximum winding temperature				130		[°C]		
Performance								
Cooling capacity			Power consumption	Current consumption	Gas flow rate	EFFICIENCY RATE		
[Btu/h]	[kcal/h]	[W]	[W]	[A]	[kg/h]	[Btu/Wh]	[Btu/Wh]	[W/W]
1090	275	319	256	1.96	6.19	4.26	1.07	1.25
Start capacitor				88-108(220)		[μF(VAC minimum)]		
Motor protection (external)								
Code				4TM757KFBYY-53 5TM757KFBYY-53				
Opening Temperature				120°C (248°F)				
Closing Temperature				69°C (156,2°F)				
Triping Current at 25°C (77°F)				11,5 A				
Reaction Time				7.5s – 14.0s				
Current Relay								
Pick Up Current (A)				6,8				
Drop-Out Current (A)				5,2				
EXTERNAL CHARACTERISTICS								
SUCTION				8.2		[mm]		
DISCHARGE				6.5		[mm]		
PROCESS				6.5		[mm]		

[Compressor : FFI 12HBKW]
Table 9-3

9.SERVICE INSTRUCTIONS

9.2.6 Compressor Troubleshooting

Compressor will not start – No hum.	Line disconnected. Starting relay open	Check the line and the starting relay contacts.
	Overload protector tripping.	Check the electrical connections.
	Thermostat not correctly adjusted.	Reset or replace the thermostat.
	Electrical connections improper or loose.	Check wiring against diagram, or tighten the connections.
Compressor will not start (hums) but trip on the overload protector.	Improperly wired.	Check wiring against diagram. Redo the electrical connections according to the electrical diagram.
	Low voltage at the compressor.	Determine reason and correct.v
	Start capacitor defective.	Determine reason and replace the capacitor if necessary.
	Relay failing to close.	Determine reason and correct, replace the relay if necessary.
	Compressor motor has a winding open or shorted.	Replace the compressor.
	Internal mechanical problem in compressor.	Replace the compressor.
Compressor starts and runs, but short cycles on overload protector.	Additional current passing through overload protector.	Check wiring diagram. Check for added fan motors, pump, etc. connected to the wrong side of protector.
	Low voltage at compressor (or unbalanced if three phase).	Determine reason and correct.
	Overload protector defective.	Check current, replace protector.
	Run capacitor defective.	Determine reason and replace.
	Excessively high discharge pressure.	Check ventilation, restrictions in cooling medium, restriction in refrigeration system.
	Excessively high suction pressure.	Check for possibility of incorrect application. Use stronger unit.
	Compressor too hot. Return gas hot.	Check refrigerant charge, repair leaks, and add gas if necessary.
	Compressor motor has a winding shorted	Replace the compressor.


9.SERVICE INSTRUCTIONS

Compressor starts, but does not switch off of start winding.	Improperly wired.	Check wiring against diagram.
	Low voltage at the compressor.	Determine reason and correct.
	Run capacitor defective.	Determine reason and replace.
	Relay failing to open.	Determine reason and correct, replace if necessary.
	Excessively high discharge pressure.	Check discharge shut-off valve, possible overcharge, or insufficient cooling at condenser.
	Compressor motor has a winding open or shorted.	Replace the compressor.
	Internal mechanical problem in compressor (tight).	Replace the compressor.

Table 9-4

9.SERVICE INSTRUCTIONS

9.2.7 Condenser Fan Motor Assembly



Motor Wire & Motor terminal

Pic 9-5

1. To replace the condenser fan motor, detach the motor terminal from the condensing unit connector (Fig 9-5).




Fig 9-11

2. Loosen the bolts of the condenser fan motor assembly from the condenser. (Fig 9-11)




Fig 9-12

3. Loosen the connecting bolts between the fan motor and fan guard. (Fig 9-13)




Fig 9-13

4. To remove the blade, loosen the bolt fixing the blade to the motor shaft. (Fig 9-13)

9.SERVICE INSTRUCTIONS

9.2.8 Replacement the Condenser and Filter Drier




Fig 9-14

1. When replacing the condenser, remove the 6 screws on the front, left and right of the base.
2. Using a gas burner, take out the joint points marked in the figure above.
3. Refer to Table 5 to confirm the size of the condenser.
4. Re-assemble in the reverse order.

9.2.9 Replacing the Service Valve





Fig 9-15

1. Using a gas burner, take out the pipes connected to the valve inlet.
2. Remove the flare nuts connected to valve outlet.
3. Loosen the screws on the service valve assembly bracket. Remove the pairs of bolts holding the valves in place.
4. Refer to Table 5 to confirm the Q·ty. and the size of the valve.
5. Reassemble in the reverse order.

9.SERVICE INSTRUCTIONS

9.3.1 Evaporator FAN Motor

WARNING : Make sure that the power is disconnected before servicing.
Allow for sufficient working space to ensure your safety
and the safety of the unit.



Pic 9-6

9.3.2 Checking for Evaporator Leaks




Pic 9-7


9.SERVICE INSTRUCTIONS

9.4 How to Check Heater.

1. Locate the door sub-heater by removing the screws of the top pan.(Fig 9-16).



2. For the location of the door side heater and the door sub heater, refer to (Fig 9-17)



DETAIL DIAGRAM

9.SERVICE INSTRUCTIONS

9.5 Door

9.5.1 How to Remove the Door Assembly




Fig 9-18




Fig 9-19

To replace the door, remove the tension between the shaft and spring.
Refer to figure 9-23.

Preparation : (1) Small size screwdriver, (2) small steel stick

WARNING : Take extra precaution when handling the spring tension.
Make sure to follow procedure.




Fig 9-20

1. Insert the steel stick between the shaft holes. (Fig 9-20)




Fig 9-21

2. To remove the tension pin, slightly turn the stick along the direction of the arrow. Maintain the position of the stick by resisting the spring tension. (Fig 9-21)




Fig 9-22

3. Turn and detach the tension pin by using the a (-) screwdriver. Avoid dropping or losing the pin. (Fig 9-22)




Fig 9-23

4. Take the steel stick and slowly loosen it toward the direction of the arrow. If tension is completely released before the stick touches the body, remove the stick from the shaft and go to the next step. (Fig 9-23)




Fig 9-24

5. If tension is still present even after completing steps 1 through 4, repeat the procedure by using the steel stick. (Fig 9-24)

6. Remove the top pan and the shaft cap. For instructions on how to remove the top pan, refer to 9.5.

9.SERVICE INSTRUCTIONS




Fig 9-25

7. While supporting the door so it does not detach, unscrew the three bolts that hold the upper hinge in place. (Fig 9-25)




Fig 9-26

8. While lifting the door up, completely detach the door from the lower hinge shaft. (Fig 9-26)

9. Attach the new door or proceed to the next step.

9.5.2 Door Tension Adjustment




Fig 9-27

1. Remove Front Cover Grill and Shaft Cap. Insert one steel stick into the shaft hole. (Fig 9-27)




Fig 9-28

2. To remove the tension pin, slightly turn the stick in the direction of the arrow. Maintain the position of the steel stick by resisting the spring tension. (Fig 9-28)




Fig 9-29

3. Turn and detach the tension pin by using a (-) screwdriver. Avoid dropping or losing the pin. (Fig 9-29)




Fig 9-30

4. Turn the stick in the direction of the arrow until the next hole is visible. Avoid dropping or losing the pin. (Fig 9-30)




Fig 9-31

5. Turn and drive the tension pin into the next step hole. (Fig 9-31)
6. Adjust the tension of the lower shaft.

9.SERVICE INSTRUCTIONS


9.5.3 Door Handle

1. Pop out the outer handle.
2. Remove four (4) screws from the inner handle.
(Two (2) screws each for top and bottom)

CAUTION : Be sure to use a door handle washer. (Pic 9-7)



Pic 9-7



Pic 9-8

9.SERVICE INSTRUCTIONS


9.5.4 Door Gasket

1. Keep the door open.
2. Firmly grasp the door gasket on the top corners with both hands.
3. Slowly pull the gasket out of the slotted groove. Continue until the gasket is removed. (Pic 9-9)
4. To install the replacement door gasket, start snapping it into the groove at the top of the door. Begin at the two corners and move evenly from each side towards the middle as shown below. (Fig 9-32)
5. Work the gasket evenly down both sides and then across the bottom. (Fig 9-32)

CAUTION : Do not stretch or bend the door gasket.



Pic 9-9



10.DIAGNOSTIC

10.1 SERVICE DIAGNOSTIC CHART

Symptom	Possible Cause	Corrective Action	References
Unit Does not run	Main power button on control box is OFF.	Press and hold "POWER ON/OFF" button on the control box.	7.3
	Voltage is too low.	Correct the electrical service so it does not vary more than +/- 10%.	
	Electronic Controller is defective.	Replace the Electronic Controller	8.1.3
	Compressor is defective.	Replace the compressor.	8.2.2
	Relay and/or capacitor is defective.	Replace the relay and/or capacitor.	
	Delay time.	It takes about one (1) minute to run the unit after plug-in.	7.9
Cabinet does not maintain proper temperature	High pressure in refrigeration system		
	- Condenser coil is too dirty.	Clean the condenser coil.	3.2
	- Refrigerant was overcharged.	Evacuate and recharge the system with proper amount of refrigerant.	
	- Condenser fan motor does not run.	Check motor electrically, replace if defective.	8.2.5
	- Evaporator fan motor does not run.	Check motor electrically, replace if defective.	8.2.6
	- Capillary tube is clogged.	Evacuate and recharge the system	
	- Clearance around the unit is insufficient.	Reinstall the unit.	4
	- Condenser air is recirculating or ambient temperature is above specification.	Reinstall the unit.	4
	System is on "Defrost Cycle".	During the defrost cycle, compressor and fan motor of the evaporator & condensing do not run. The cycle is terminated by both temp (16°C) and time(within 20 minutes). Factory defrost setting is 4 times a day for both freezers and refrigerators.	7.9

E REFRIGERATION
VEREST

10.1 SERVICE DIAGNOSTIC CHART

Cabinet does not maintain proper temperature	Refrigerant charge is low.	Find and repair any refrigeration leak, replace the filter drier, evacuate and recharge the system.	
	Temp. control system problems.		
	- Temperature setting is incorrect.	Reset the desired temperature.	7
	- Control is defective.	Replace the circuit board(s).	8.1.3
	Condenser coil is too dirty.	Clean the condenser coil. (Factory recommends condenser cleaning once a month)	3.2
	Frozen evaporator coil.		
	- Air flow is restricted.	Arrange product for proper interior airflow, check the evaporator coil for debris.	8.4
(Freezers only)	- Pressure(Vacuum) relief control is open.	Check for leaks, repair or replace if necessary.	
	- Defrost heater is defective.	Replace the defrost heater.	8.2.7
	- Drain pan heater is defective.	Replace the evaporator drain cover.	8.4.1
	- Insufficient number of defrost setting.	Defrost the evaporator coil first, then reset sufficient number of defrost cycle.	
	- Door is open or gasket is not sealing properly.	Close door propely, adjust tension and/or replace gasket if necessary.	8.7
	- Light switch is not properly pressed	Adjust location of light switch bracket.	
	- Light switch is defective.	Check electrically and replace the door switch if defective.	8.3.3
Compressor does not operate	Wiring problem.	Check for and correct any incorrect connections. Check for any loose or bad connections to the control box.	8.1.1
	Relay is defective.	Check the start relay, replace if necessary.	8.2.2
	Capacitor is defective.	Check the start relay, replace if nessarry.	8.2.2

10.DIAGNOSTIC

10.1 SERVICE DIAGNOSTIC CHART

Door(s) difficult to open.	Pressure(vacuum) relief control is not functioning.	Check the component, replace if defective.	
	Wrong installation.	Check casters and floor to see if the unit is properly leveled.	4
Water is leaking	In the Cabinet.		
	– Drainage tube is not inserted.	Open the evaporator drain cover and check the drainage tube.	8.4
	– Evaporator drain cover is broken.	Check if there is any crack, replace if damaged.	8.4
	Out of the Cabinet.		
	– Condensate pan heater located at bottom of unit is defective.	Check electrically first, and replace the wire type condensate pan heater if defective.	8.5
Noise	In the cabinet.		
	– Evaporator motor fan damaged due to ice built on evaporator coil.	Check the defrost heater or control box to see if they are energizing. Replace defrost heater or Electronic Controller if defective.	8.2.7
	Out of Cabinet.		
	– Condensing motor fan blades are broken.	Replace the fan blades.	8.2.5
	– Condensing motor is defective.	Check motor, replace if necessary.	8.2.5