











NOTE: Seal all splice terminals with Glyptol

Clean and scrape all wire connections