

FWM3-42 Wiring Schematics (Continued)




Figure 7.6 FWM 3-42 MB2 & SB2 Interface Cable Schematic

FWM3-42 Wiring Schematics




Figure 7.4 FWM 3-42 MB1 Interface Cable Schematic





Figure 7.3, MB2 & SB2 Interface Cable Schematic







Figure 7.1, MB1 Interface Cable Schematic

SECOND TEMPERATURE CONTROLLER ON FWM3-42 ONLY



* CONNECT WIRE #4 TO 240V TERMINAL FOR 240VAC AND 230VAC CE UNITS (SHOWN)
 CONNECT WIRE #4 TO 208V TERMINAL FOR 208 VAC UNITS
 120 VAC UNITS USE A 120V TRANSFORMER