


MPF50S

MPF50S Parts List



MPF50S

MPF50S Parts List

#	PART #	DESCRIPTION	QTY	Note
1	8236231SP	Pan, Filter	1	
2	8065223SP	Base Assembly	1	[1]
3	9009542	Bracket, Motor-Mount – All MPF50S	1	
4	9001748	Brace, End- Filter Base	1	
4a	9008585	Brace, Rear Cross- Filter Base	1	
5	8102805	Caster - 2"	1	[2]
6	8102806	Caster - 2" Swivel	1	[3]
7	8090475	Screw - #10-32 x 0.3125" Hex	1	
8	9003751	Bracket, Standoff	1	
9	8122300	Screen, Filter Paper Support	1	
9a	8030003	Paper, Filter 17.75" x 12.5" 100 sheets	1	
9b	8030002	Powder, Filter	1	
10	8104440	Ring, Hold-down	1	
11	2302836	Lid, Filter Pan	1	
12	8235950	Crumb basket	1	
13	8103162	Handle, Pan Lid 802-	1	
14	8261379	Screw, #10 X 0.5-inch Phillips Truss Head	10	[4]
15	8090184	Washer, #10 LK ZP	1	[4]
16	8090020	Nut Cap 10-24 NP	1	[4]
17	1067847	Complete Hose/wand assembly	1	
18	8103303	Hose	1	
19	8261712	Motor and Gasket Kit - 115V/50-60 Hz	1	[5]
19a	8261270	Motor and Gasket Kit - 220-240V/50-60 Hz	1	[5]
20	8261264	Pump Kit - 4 GPM	1	[6]
21	8130265	Nipple - 0.5" x 2.5" NP	1	
22	8130062	Elbow - 0.5" BM x 90°	1	
23	8063844	Heater Strip, 120V 40W	1	
23a	8067435	Heater Strip, 230/240V 70W	1	
24	8130165	Elbow - 0.5" x 90° NPT Street	1	
25	8130022	Nipple, 0.5" Close NPT BM	1	
26	8101435	Flexline - 0.5" OD x 12" L - SS	1	
27	8130545	Union, 0.5 x 0.5" Flexline Hose	1	
28	8071219	Receptacle - 3-Wire	1	[7]
29	8071224	Cord, Power - 3-Wire 115V	1	
30	8074317	Cord, Power – Euro 3-Wire 230/240V	1	
31	9108587	Panel, Outer - Left Side	1	
31a	9108586	Panel, Outer - Right Side	1	
32	9103788	Holder, Power Cord	1	
33	9122616	Bracket, Handle- Right	1	
33a	9112616	Bracket, Handle- Left	1	
34	8261380	Screw, 0.25-20 X 0.5-inch Slotted Pan Head	5	[8]
35	8103508	Handle, Portable Filter	1	
36	8261389	Screw - 0.25"-20 x 0.75" Hex Head ZP	10	
37	8100219	Spacer, Handle Bolt	1	
38	8090047	Nut, Cap- 0.25-20 High Profile S/S	1	
39	8240403	Panel, Control	1	

MPF50S

MPF50S Parts List

#	PART #	DESCRIPTION	QTY	Note
39a	9100982	Panel, Switch	1	
40	8021438	Label, Switch Plate	1	
40a	8071041	Toggle Switch - 2-Way	1	
41	8071060	Light, Indicator- Red Lens (Filter Indicator Light) 120V	1	
41a	8071086	Light, Indicator- White Lens (Heater Indicator Light) 230/240V	1	[9]
42	8071041	Toggle Switch - 2-Way	1	
43	8071061	Light, Indicator- White Lens (Heater Indicator Light) 120V	1	
43a	8071086	Light, Indicator- White Lens (Heater Indicator Light) 230/240V	1	[9]

PART NOTES:

- [1] - Includes items 5 & 6
- [2] - Without Brake
- [3] - With Brake
- [4] - Lid Handle
- [5] - Includes Motor and Gasket
- [6] - Includes Pump and Gasket
- [7] - 120V Domestic Units Only
- [8] - For Handle Bracket
- [9] - Europe Only