

Frigidaire

Factory Parts Catalog

Product No.	FN38LPDC	FN38NGDC
Series	Grill & Cart	Grill & Cart
Market	NECO	NECO
Color	stainless steel	stainless steel
Owner's Guide	FD/FN38IMD	FD/FN38IMD



Electrolux Major Appliances
 North & Latin America
 P.O. BOX 212378
 AUGUSTA, GA 30917


Publication No.
5995436218
 05/05/05
 (EN/SERVICE/BJH)
 099

GAS GRILL

Model No.
FN38LPD / FN38NGD

Copyright © 2005 Electrolux Home Products, Inc.
 All rights reserved.

RECOMMENDED SPARE PARTS




FN38-A

RECOMMENDED SPARE PARTS

		<i>Model Index:</i>	
		A FN38LPD (FN38LPDC)	
		B FN38NGD (FN38NGDC)	
POS. NO	PART NO.		DESCRIPTION
1	5304444388	A B	Handle End, hood, left
2	5304444389	A B	Handle, hood, 32 inch
3	5304444390	A B	Handle End, hood, right
4	5304444391	A B	Magnet, door
5 #	5304444392	A B	Guage, temperature
6 #	5304444393	A B	Electrode, infrared burner, back
7 #	5304444453	A B	Burner, infrared, back
8	5304445084	A B	Cover, infrared burner
9 #	5304444397	A B	Burner, main
10	5304444398	A B	Flavor Grid, igniter cover, bottom, angle
11	5304444399	A B	Flavor Grid, burner cover, top, angle
12	5304444400	A B	Grate, side burner
13	5304444401	A B	Shelf, side burner
14	5304444420	A B	Door, cart, left
15	5304444440	A B	Door, cart, right
16	5304444404	A B	Housing, igniter battery
17	5304444405	A B	Knob, burner
18	5304444406	A B	Bezel, knob
19	5304444407	A B	Hood, grill
20	5304444408	A B	Grate, main burner
21 #	5304444674	A B	Igniter, 4-pole, no ground, with bracket
22 #	5304445087	A -	Orifice, LP, side burner, with holder
22 #	5304445088	- B	Orifice, NG, side burner, with holder
23 #	5304445078	A -	Valve, side burner, LP
23 #	5304445079	- B	Valve, side burner, NG
24 #	5304444414	A B	Manifold
25	5304444415	A B	Panel, cart, back
26	5304444416	A B	Panel, cart, right side
27	5304444417	A B	Base, cart
28	5304444418	A B	Channel, wheel, swivel
29	5304444419	A B	Door Stop
30	5304445083	A B	Channel, wheel, fixed
31	5304444421	A B	Handle, door, 9.375 inch
32 #	5304444675	A -	Regulator, LP
32 #	5304444424	- B	Regulator, NG
33	5304444425	A B	Handle End, door, left
34	5304444426	A B	Handle End, door, right
35	5304444427	A B	Panel, cart, left side
36	5304444428	A B	Knob, infrared burner
37	5304444429	A B	Bezel, infrared knob
38	5304444430	A B	Shelf, warming rack
39 #	5304444431	A B	Wire, igniter, positive
40 #	5304444432	A B	Wire, igniter, negative
41 #	5304445074	A -	Valve, infrared burner, LP
41 #	5304445075	- B	Valve, infrared burner, NG
42 #	5304445069	A -	Valve, burner, main/side, LP
42 #	5304445070	- B	Valve, burner, main/side, NG
43	5304445086	A B	Shelf, left side, folding
44	5304444438	A B	Tray, drip pan

RECOMMENDED SPARE PARTS



FN38-A

RECOMMENDED SPARE PARTS

Model Index: A FN38LPD (FN38LPDC)
B FN38NGD (FN38NGDC)

POS. NO	PART NO.		DESCRIPTION
45 #	5304444439	A B	Electrode, main burner
46	5304445090	A B	Bracket, folding shelf
47	5304445082	A B	Panel, igniter access
48	5304444402	A B	Cap, side burner
49	5304444403	A B	Burner Head, side burner
50 #	5304444548	A B	Motor, rotisserie
51	5304445091	A B	Spit, rotisserie
52	5304444551	A B	Fork, rotisserie
53 #	5304447641	A -	Elbow, LP, IR burner rear, with orifice
53 #	5304447642	- B	Elbow, NG, IR burner rear, with orifice
54 #	5304447646	A B	Hose, gas, infrared burner, rear
55 #	5304447638	A B	Elbow, gas fitting, manifold-to-T
56 #	5304447639	A B	Connector, T
57 #	5304447640	A B	Hose, gas, 16", to side burner
58 #	5304446174	A B	Hose, gas, 10", main supply
59 #	5304447624	A B	Fitting, main connection
60 #	5304447623	A B	Elbow, main connection
*	5304444441	A B	Bolt, valve/manifold
*	5304444442	A B	Bolt, wheel & cart
*	5304444443	A B	Nut, door, bottom pivot
*	5304444444	A B	Screw, door, bottom pivot
*	5304445048	A B	Screw, bezel/valve
*	5304444446	A B	Screw, hood handle end
*	5304444447	A B	Screw, self-tapping
*	5304444661	A B	Wire, igniter, infrared burner
*	5304444449	A B	Wire, igniter, main burner, left & right
*	5304444696	A B	Wire, igniter, side burner, rear