

Parts Catalog



Model CPRG30

ELECTRIC ROLLER GRILL

MODELS:
CPRG30 & CPRG50

01-20-2011
IMPORTANT!

TO EXPEDITE SHIPMENT OF PARTS, ALWAYS SPECIFY MODEL, REV,
PART NUMBER, AND SERIAL NUMBER OF SLICER.

GLOBE FOOD EQUIPMENT COMPANY

2215 East River Road
Dayton, Ohio 45439

Parts Department


Toll Free 1-800-745-6238 · Fax (937) 290-0585

E-Mail: globeinfo@globeslicers.com

Website: www.globeslicers.com

Not for resale

CPRG30 & CPRG50 ROLLER GRILL COMPONENTS



CPRG30 & CPRG50 PARTS LIST

Item	Description	Part Numbers		Qty	Item	Description	Part Numbers		Qty
		SRG30	SRG50				SRG30	SRG50	
1	Screw	-	-	8	19	Knob	U02101155013	-	2
2	Side Panel	-	-	2	20	Grill Body	-	-	1
3	Chain	U01021005010	-	1	21	Mica Plate	U01991090026	-	1
4	Motor Gear	U01021005059	-	1	22	Power Cord & Plug	U03021205012	-	1
5	Motor	U03011200004	-	1	23	Strain Relief	U02101155021	-	1
6	Chain Adjusting Assy	U06051470237	-	1	24	Power Switch	U03041215027	-	1
7	Spring Plate	U01051025827	-	1	25	Heating Element	U03061225040	U03061225042	11
8	Screw	-	-	4	26	Screw	-	-	15
9	Foot	U02121165003	-	4	27	M4 Nut	-	-	13
10	M5 Washer	-	-	4	28	M4 Washer	-	-	14
11	Nut	-	-	7	29	Right Baffle	-	-	1
12	E-Clip Retaining Ring	U66991845009	-	2	30	Gum Cover	U02101155052	-	22
13	Gear	U01021005035	-	3	31	Quadric Sealing	U02101155055	-	22
14	Sleeve	U01021005067	-	1	32	Roller	U01091050029	U01091050028	11
15	Base Plate	-	-	1	33	Left Baffle (Upper)	-	-	1
16	Screw	-	-	5	34	Left Baffle (Lower)	-	-	1
17	Indicator Light	U03091240005	-	2	35	Element Fixing Plate	-	-	1
18	Thermostat	U03041215007	-	2	36	Spring	U01011000006	-	1

WIRING DIAGRAM, CPRG30/CPRG50

