




GS 130

GLOBE GS130

ITEM	PART NO.	DESCRIPTION	QTY
1	E89156218	Platter	1
2	E89182809	Sheet, Display, Panel	2
3	E89182902	Nameplate, Spec	1
4	E89155409	Case, Upper	1
5	E89181820	Sheet, Keyboard	1
6	E89156105	Rubber, Plate Support	4
7	E89066806	Screw, Limit	4
8	E89155606	Plate Support	1
9	E89160919	Transformer AS	1
10	E89064200	Load Cell, C2G1-10K	1
11	E89172301	PWB, PK-201	1
12	E89214803	PWB, PK-200A	1
13	E89155907	Bracket, Display, Rear	2
14	E89161108	Harness, S2: Display	1
15	E89155803	Bracket, Display, Front	2
16	E89156011	Base	1
17	E23305205	Leg, Adjusting	4
18	E89066505	Plate A	3
19	E89091402	Level Unit	1
20	E89211604	Bolt Seal	1
21	E89155700	Plate, Connector	1
22	E89161201	Harness, S3, Power	1
23	E89054003	Cord, Bush	1
24	E00476106	Push Rivet	2
25	E89193100	Plate B, Level	1