



CATALOG OF REPLACEMENT PARTS




HHTC SERIES HOT TWO-TIER CASE

HHTC4	ML-132073
HHTC6	ML-132074
HHTC8	ML-132075


Table of Contents

3	Controls and Electrical Components
5	Glass and Doors
7	Lights and Heating Components



CONTROLS AND ELECTRICAL COMPONENTS


ILLUS.	PART NO.	NAME OF PART	AMT.
PL-57160			
1	00-877707-00061	Mach. Screw M5 X 12 Hex Button Hd.	AR
2	00-877708-00409	Panel – Control (SST) (ML-132073)	1
3	00-877708-00609	Panel – Control (SST) (ML-132074)	1
4	00-877708-00809	Panel – Control (SST) (ML-132075)	1
5	00-877707-00028	Switch – Rotary (Main Power)	1
6	00-877707-00029	Switch – Toggle (Lights & Heaters)	3
7	00-356840	Holder – Fuse	3
8	00-422905-00097	Fuse (10 Amp.)	3
9	00-877707-00004	Controller (Self-Service) (Includes Sensor)	1
10	00-877707-00030	Block – Terminal (1-2-3)	1
11	00-358712-00003	Jumpers – Copper	AR
12	00-877707-00056	Block – Terminal (4-5-6)	1
13	00-360151	Relay	1
14	00-422800-00068	Block – Terminal (6-Position)	2
15	00-877707-00022	Transformer (230/12 V.)	1
16	00-356840	Holder – Fuse	1
17	00-877707-00024	Fuse (2.5 Amp., 12 V.)	1
18	00-877707-00021	Transformer (208/230 V.)	1



GLASS AND DOORS

GLASS AND DOORS

ILLUS.	PART NO.	NAME OF PART	AMT.
PL-57162			
1	00-877708-00403	Glass – Front (Bottom) (ML-132073)	1
2	00-877708-00603	Glass – Front (Bottom) (ML-132074)	1
3	00-877708-00803	Glass – Front (Bottom) (ML-132075)	1
4	00-877708-00401	Strip – Clear (For Top & Bottom Glass) (ML-132073)	1
5	00-877708-00601	Strip – Clear (For Top & Bottom Glass) (ML-132074)	1
6	00-877708-00801	Strip – Clear (For Top & Bottom Glass) (ML-132075)	1
7	00-877707-00308	Cylinder – Lift (300 N) (ML-132073 & ML-132075)	AR
8	00-877708-00608	Cylinder – Lift (600 N) (ML-132074)	AR
9	00-357553-00055	Set Screw M4 X 5	1
10	00-877708-00005	Cylinder Lift Mounting Assy. (LH)	1
11	00-877708-00402	Glass – Front (Canopy) (ML-132073)	1
12	00-877708-00602	Glass – Front (Canopy) (ML-132074)	1
13	00-877708-00802	Glass – Front (Canopy) (ML-132075)	1
14	00-877708-00004	Cylinder Lift Mounting Assy. (RH)	1
15	00-877708-00414	Panel – Heat & Light (Customer) (ML-132073)	1
16	00-877708-00614	Panel – Heat & Light (Customer) (ML-132074)	1
17	00-877708-00814	Panel – Heat & Light (Customer) (ML-132075)	1
18	00-877708-00002	Glass – Side	2
19	00-877708-00415	Panel – Heat & Light (Operator) (ML-132073)	1
20	00-877708-00615	Panel – Heat & Light (Operator) (ML-132074)	1
21	00-877708-00815	Panel – Heat & Light (Operator) (ML-132075)	1
22	00-877708-00404	Board – Cutting (ML-132073)	1
23	00-877708-00604	Board – Cutting (ML-132074)	1
24	00-877708-00804	Board – Cutting (ML-132075)	1
25	00-877708-00413	Vent – Fixed (ML-132073)	1
26	00-877708-00613	Vent – Fixed (ML-132074)	1
27	00-877708-00813	Vent – Fixed (ML-132075)	1
28	00-877708-00410	Track – Upper (ML-132073)	1
29	00-877708-00610	Track – Upper (ML-132074)	1
30	00-877708-00810	Track – Upper (ML-132075)	1
31	00-877708-00407	Strip – Clear (For Door Top) (ML-132073)	2
32	00-877708-00607	Strip – Clear (For Door Top) (ML-132074)	2
33	00-877708-00807	Strip – Clear (For Door Top) (ML-132075)	4
34	00-877708-00003	Strip – Clear (For Side of Door)	AR
35	00-877708-00406	Door – Sliding (Mirror) (RH) (ML-132073)	1
36	00-877708-00606	Door – Sliding (Mirror) (RH) (ML-132074)	1
37	00-877708-00806	Door – Sliding (Mirror) (RH) (ML-132075)	2
38	00-877708-00411	Track – Lower (ML-132073)	1
39	00-877708-00611	Track – Lower (ML-132074)	1
40	00-877708-00811	Track – Lower (ML-132075)	1
41	00-877707-00055	Block – Slide (For Door) (Nylon)	AR
42	00-877708-00405	Door – Sliding (Mirror) (LH) (ML-132073)	1
43	00-877708-00605	Door – Sliding (Mirror) (LH) (ML-132074)	1
44	00-877708-00805	Door – Sliding (Mirror) (LH) (ML-132075)	2
45	00-877707-00058	Knob – Slide Door	AR
46	00-357553-00104	Screw M4 X 30	AR
47	00-358521-00042	Washer	AR
48	00-877707-00089	Bracket – Door Handle	AR
49	00-877707-00090	Bumper – Rubber	AR
50	00-877708-00006	Leg – Black (4 In.)	4
51	00-425900-00334	Stopper – Leg	4
52	00-877708-00412	Rack – Upper (ML-132073)	1
53	00-877708-00612	Rack – Upper (ML-132074)	1
54	00-877708-00812	Rack – Upper (ML-132075)	1
55	00-877708-00015	Block – White Sliding (ML-132075)	1
56	00-877708-00014	Support – Upper Rack (ML-132075)	1
57	00-877708-00007	Foot – Upper Rack	4
58	00-877708-00011	Holder – Side Glass (Left Side)	1
59	00-877708-00012	Holder – Side Glass (Right Side)	1
60	00-877707-00064	Screw M4 X 6	AR
61	00-357553-00034	Washer	AR
	00-118363	Logo – Hobart 4 In. (Mylar)	1



LIGHTS AND HEATING COMPONENTS

LIGHTS AND HEATING COMPONENTS

ILLUS.	PART NO.	NAME OF PART	AMT.
PL-57161			
1	00-877708-00008	Bulb – Coated (100 W., 10,000 Hour)	AR
2	00-877708-00001	Socket – Bulb	AR
3	00-877707-00008	Heater – Upper (250 W.) Ceramic	AR
4	00-877707-00047	Block – Terminal (2-Position) (Ceramic)	AR
5	00-877707-00009	Fan – Well Heater	AR
6	00-877708-00013	Plate – Element Mounting	AR
7	00-877707-00006	Element – Well Heater (1500 W., 208 V.)	AR
8	00-877707-00053	Element – Well Heater (1500 W., 230 V.)	AR

