


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# WHIRLPOOL KCMS1555SSS Owner's Manual

[Shop genuine replacement parts for WHIRLPOOL  
KCMS1555SSS](#)




[Find Your WHIRLPOOL Microwave Parts - Select From 1350 Models](#)

----- Manual continues below -----

# EXPLODED VIEW

## INTRODUCTION


MODEL : KCMS1555SBL  
KCMS1555SSS  
KCMS1555SWH




P/NO : MFL41636801

# DOOR PARTS

FOR MODEL : KCMS1555SBL  
KCMS1555SWH




FOR MODEL : KCMS1555SSS




CONTROL PANEL PARTS


FOR MODEL : KCMS1555SBL  
KCMS1555SWH




FOR MODEL : KCMS1555SSS




# OVEN CAVITY PARTS




LATCH BOARD PARTS




INTERIOR PARTS



# BASE PLATE PARTS



# SENSOR PARTS



# Replacement Parts list

FOR MODEL : KCMS1555SBL

Rev.1 Sep 13, 2007

| LOC. NO. | PART NO.    | DESCRIPTION                            | SVC | ALTERNATE   | REMARK |
|----------|-------------|----------------------------------------|-----|-------------|--------|
| *01      | MFL37573601 | Manual,Owners                          | R   |             |        |
| *05      | MEZ34344601 | Label,Cooking Guide                    | R   |             |        |
| *07      | 3840W1T001X | Card,Technical                         | R   |             |        |
| *10      | 3890W3Y767B | Box                                    | R   |             |        |
| 13213A   | 3213W1A031P | Frame Assembly,Door                    | R   |             |        |
| 13352A   | 3352W1A142A | Window,Screen                          | R   |             |        |
| 13536A   | 3536W1A004A | Tape,Sealing                           | R   |             |        |
| 13552A   | 3552W0A012A | Cover,Choke                            | R   |             |        |
| 13581A   | ADC35638603 | Door Assembly                          | R   |             |        |
| 13720D   | MGC39841301 | Panel,Door                             | R   |             |        |
| 14026A   | 4026W2A016A | Locker                                 | R   |             |        |
| 14970A   | 4970WRA001B | Spring                                 | R   |             |        |
| 15006A   | 5006W3A012A | Cap,Choke Cover                        | R   |             |        |
| 23506A   | MFM41152301 | Membrane                               | R   |             |        |
| 23551A   | AGM36115301 | Parts Assembly(Panel,Control+Membrane) | R   |             |        |
| 23572A   | MGC39841501 | Panel,Control                          | R   |             |        |
| 24510L   | 4510W3L003B | Lever                                  | R   |             |        |
| 24781M   | ACM35638503 | Controller Assembly,Keypad             | R   |             |        |
| 24970A   | 4B72023B    | Spring                                 | R   |             |        |
| 250201   | MBG39841601 | Button                                 | R   |             |        |
| 268711   | 6871W1S197P | PCB Assembly,Sub                       | R   |             |        |
| 33052A   | 3052W2A021A | Cover,Resin                            | R   |             |        |
| 33112U   | 3112W1U037Q | Case,U Bending                         | R   |             |        |
| 33390G   | 3390W1A027A | Tray,Glass                             | R   |             |        |
| 34370T   | 4370W1A006B | Shaft,Turntable                        | R   |             |        |
| 34930W   | 4930W3B029A | Holder,Wire                            | R   |             |        |
| 35012A   | 5012W3A020C | Insulator                              | R   |             |        |
| 35889A   | 5889W2A015K | Turntable Assembly                     | R   |             |        |
| 36549S   | 6549W1S011W | Motor, AC Synchronous                  | R   | 6549W1S017J |        |
| 43500A   | 3500W1A018A | Holder,Locker                          | R   |             |        |
| 43501A   | 3501W1A053A | Holder Assembly,Locker                 | R   |             |        |
| 466001   | 6600W1K001D | Switch,Micro                           | R   |             |        |
| 466003   | 6600W1K001C | Switch,Micro                           | R   |             |        |
| 50CZZH   | 0CZZW1H004C | Capacitor,High Voltage                 | R   | 0CZZW1H004P |        |
| 50CZZH   | 0CZZW1H004C | Capacitor,High Voltage                 | R   | 0CZZW1H005A |        |
| 50FZZA   | 3B74133Q    | Fuse,Time Delay                        | R   | 3B74133K    |        |
| 54810C   | 4810W4C003B | Bracket,Capacitor                      | R   |             |        |
| 54974S   | 4974W0A003C | Guide,Suction                          | R   |             |        |
| 54974T   | 5208W1A012B | Duct                                   | R   |             |        |
| 54980A   | 4980W3A038A | Supporter                              | R   |             |        |
| 55262A   | 5208W1A017A | Duct                                   | R   |             |        |
| 55900A   | 5900W1A007B | Fan                                    | R   |             |        |
| 56170D   | 6170W1D077J | Transformer,high voltage               | R   | 6170W1D112D |        |
| 56201A   | 6201W1A014A | Filter Assembly,Noise                  | R   | 6201W1A014B |        |
| 56201A   | 6201W1A014A | Filter Assembly,Noise                  | R   | 6201W1A014E |        |
| 56201A   | 6201W1A014A | Filter Assembly,Noise                  | R   | 2B72130M    |        |
| 56324A   | 6324W1A001L | Magnetron                              | R   | 6324W1A001B |        |
| 56411A   | 6411W1A019V | Power Cord Assembly                    | R   | 6411W1A019W |        |
| 56411A   | 6411W1A019V | Power Cord Assembly                    | R   | 6411W1A019X |        |
| 56501A   | 6501W1A006A | Sensor Assembly                        | R   |             |        |

| LOC. NO. | PART NO.    | DESCRIPTION         | SVC | ALTERNATE   | REMARK |
|----------|-------------|---------------------|-----|-------------|--------|
| 56549F   | 6549W1F009C | Motor,AC Fan        | R   |             |        |
| 56851D   | 6851W1A002A | Cable,Assembly      | R   | 6021W3B001R |        |
| 56851D   | 6851W1A002A | Cable,Assembly      | R   | 6021W3B001N |        |
| 568771   | 6877W1A506E | Harness,Single      | R   |             |        |
| 56912B   | 6912W3B002L | Lamp,Incandescent   | R   |             |        |
| 56930V   | 6930W1A001L | Thermostat          | R   | 6930W1A001C |        |
| 56930V   | 6930W1A001L | Thermostat          | R   | 6930W1A004N |        |
| 63302A   | 3302W0A036B | Plate,Base          | R   |             |        |
| 63303A   | 3303W0A019B | Plate Assembly,Base | R   |             |        |
| 65006B   | 5006W3A019A | Cap,Base Plate      | R   |             |        |
| 948501   | 3B72244T    | Damper              | R   |             |        |
| WEB001   | 1EBF0402494 | Screw,Taptite       | R   |             |        |
| WSZ002   | 1SBF0402418 | Screw,Taptite       | R   |             |        |
| WSZ062   | 4000W4A003A | Screw,Customized    | R   |             |        |
| WSZ085   | 4B70188C    | Screw,Customized    | R   |             |        |
| WSZ185   | 1SZZW2A002A | Screw,Customized    | R   |             |        |
| WTP004   | 1TPL0302418 | Screw,Tapping       | R   |             |        |
| WTP013   | 1TPL0402418 | Screw,Tapping       | R   |             |        |
| WTT010   | 1TTG0402422 | Screw,Tapping       | R   |             |        |
| WTT021   | 1TTL0402418 | Screw,Tapping       | R   |             |        |
| WTT028   | 1TTL0402818 | Screw,Tapping       | R   |             |        |
| WTT037   | 1TTL0403818 | Screw,Tapping       | R   |             |        |

# Replacement Parts list

FOR MODEL : KCMS1555SSS

Rev.1 Sep 13, 2007

| LOC. NO. | PART NO.    | DESCRIPTION                                  | SVC | ALTERNATE   | REMARK |
|----------|-------------|----------------------------------------------|-----|-------------|--------|
| *01      | MFL37573601 | Manual,Owners                                | R   |             |        |
| *05      | MEZ34344601 | Label,Cooking Guide                          | R   |             |        |
| *07      | 3840W1T001X | Card,Technical                               | R   |             |        |
| *10      | 3890W3Y767B | Box                                          | R   |             |        |
| 13213A   | 3213W1A031P | Frame Assembly,Door                          | R   |             |        |
| 13352A   | 3352W1A142A | Window,Screen                                | R   |             |        |
| 13536A   | 3536W1A004A | Tape,Sealing                                 | R   |             |        |
| 13551A   | AGM35659402 | Parts Assembly(Panel,Door+Cover)             | R   |             |        |
| 13552A   | 3552W0A012A | Cover,Choke                                  | R   |             |        |
| 13581A   | ADC35638604 | Door Assembly                                | R   |             |        |
| 14026A   | 4026W2A016A | Locker                                       | R   |             |        |
| 14970A   | 4970WRA001B | Spring                                       | R   |             |        |
| 15006A   | 5006W3A012A | Cap,Choke Cover                              | R   |             |        |
| 23551A   | AGM35659502 | Parts Assembly(Panel,Control+Cover+Membrane) | R   |             |        |
| 23551B   | AGM35659602 | Parts Assembly(Button+Cover)                 | R   |             |        |
| 24510L   | 4510W3L003B | Lever                                        | R   |             |        |
| 24781M   | ACM35638504 | Controller Assembly,Keypad                   | R   |             |        |
| 24970A   | 4B72023B    | Spring                                       | R   |             |        |
| 268711   | 6871W1S197P | PCB Assembly,Sub                             | R   |             |        |
| 33052A   | 3052W2A021A | Cover,Resin                                  | R   |             |        |
| 33112U   | 3112W1U037P | Case,U Bending                               | R   |             |        |
| 33390G   | 3390W1A027A | Tray,Glass                                   | R   |             |        |
| 34370T   | 4370W1A006B | Shaft,Turntable                              | R   |             |        |
| 34930W   | 4930W3B029A | Holder,Wire                                  | R   |             |        |
| 35012A   | 5012W3A020C | Insulator                                    | R   |             |        |
| 35889A   | 5889W2A015K | Turntable Assembly                           | R   |             |        |
| 36549S   | 6549W1S011W | Motor, AC Synchronous                        | R   | 6549W1S017J |        |
| 43500A   | 3500W1A018A | Holder,Locker                                | R   |             |        |
| 43501A   | 3501W1A053A | Holder Assembly,Locker                       | R   |             |        |
| 466001   | 6600W1K001D | Switch,Micro                                 | R   |             |        |
| 466003   | 6600W1K001C | Switch,Micro                                 | R   |             |        |
| 50CZZH   | 0CZZW1H004C | Capacitor,High Voltage                       | R   | 0CZZW1H004P |        |
| 50CZZH   | 0CZZW1H004C | Capacitor,High Voltage                       | R   | 0CZZW1H005A |        |
| 50FZZA   | 3B74133Q    | Fuse,Time Delay                              | R   | 3B74133K    |        |
| 54810C   | 4810W4C003B | Bracket,Capacitor                            | R   |             |        |
| 54974S   | 4974W0A003C | Guide,Suction                                | R   |             |        |
| 54974T   | 5208W1A012B | Duct                                         | R   |             |        |
| 54980A   | 4980W3A038A | Supporter                                    | R   |             |        |
| 55262A   | 5208W1A017A | Duct                                         | R   |             |        |
| 55900A   | 5900W1A007B | Fan                                          | R   |             |        |
| 56170D   | 6170W1D077J | Transformer,high voltage                     | R   | 6170W1D112D |        |
| 56201A   | 6201W1A014A | Filter Assembly,Noise                        | R   | 6201W1A014B |        |
| 56201A   | 6201W1A014A | Filter Assembly,Noise                        | R   | 6201W1A014E |        |
| 56201A   | 6201W1A014A | Filter Assembly,Noise                        | R   | 2B72130M    |        |
| 56324A   | 6324W1A001L | Magnetron                                    | R   | 6324W1A001B |        |
| 56411A   | 6411W1A019V | Power Cord Assembly                          | R   | 6411W1A019W |        |
| 56411A   | 6411W1A019V | Power Cord Assembly                          | R   | 6411W1A019X |        |
| 56501A   | 6501W1A006A | Sensor Assembly                              | R   |             |        |
| 56549F   | 6549W1F009C | Motor,AC Fan                                 | R   |             |        |
| 56851D   | 6851W1A002D | Cable,Assembly                               | R   | 6851W1A002E |        |

| LOC.<br>NO. | PART NO.    | DESCRIPTION         | SVC | ALTERNATE   | REMARK |
|-------------|-------------|---------------------|-----|-------------|--------|
| 568771      | 6877W1A506E | Harness,Single      | R   |             |        |
| 56912B      | 6912W3B002L | Lamp,Incandescent   | R   |             |        |
| 56930V      | 6930W1A001L | Thermostat          | R   | 6930W1A001C |        |
| 56930V      | 6930W1A001L | Thermostat          | R   | 6930W1A004N |        |
| 63302A      | 3302W0A036B | Plate,Base          | R   |             |        |
| 63303A      | 3303W0A019B | Plate Assembly,Base | R   |             |        |
| 65006B      | 5006W3A019A | Cap,Base Plate      | R   |             |        |
| 948501      | 3B72244T    | Damper              | R   |             |        |
| WEB001      | 1EBF0402494 | Screw,Taptite       | R   |             |        |
| WSZ002      | 1SBF0402418 | Screw,Taptite       | R   |             |        |
| WSZ062      | 4000W4A003A | Screw,Customized    | R   |             |        |
| WSZ085      | 4B70188C    | Screw,Customized    | R   |             |        |
| WSZ185      | 1SZZW2A002A | Screw,Customized    | R   |             |        |
| WTP004      | 1TPL0302418 | Screw,Tapping       | R   |             |        |
| WTP013      | 1TPL0402418 | Screw,Tapping       | R   |             |        |
| WTT010      | 1TTG0402422 | Screw,Tapping       | R   |             |        |
| WTT021      | 1TTL0402418 | Screw,Tapping       | R   |             |        |
| WTT028      | 1TTL0402818 | Screw,Tapping       | R   |             |        |
| WTT037      | 1TTL0403818 | Screw,Tapping       | R   |             |        |

# Replacement Parts list

FOR MODEL : KCMS1555SWH

Rev.1 Sep 13, 2007

| LOC. NO. | PART NO.    | DESCRIPTION                            | SVC | ALTERNATE   | REMARK |
|----------|-------------|----------------------------------------|-----|-------------|--------|
| *01      | MFL37573601 | Manual,Owners                          | R   |             |        |
| *05      | MEZ34344601 | Label,Cooking Guide                    | R   |             |        |
| *07      | 3840W1T001X | Card,Technical                         | R   |             |        |
| *10      | 3890W3Y767B | Box                                    | R   |             |        |
| 13213A   | 3213W1A031Q | Frame Assembly,Door                    | R   |             |        |
| 13352A   | 3352W1A142A | Window,Screen                          | R   |             |        |
| 13536A   | 3536W1A004A | Tape,Sealing                           | R   |             |        |
| 13552A   | 3552W0A012A | Cover,Choke                            | R   |             |        |
| 13581A   | ADC35638602 | Door Assembly                          | R   |             |        |
| 13720D   | MGC39841302 | Panel,Door                             | R   |             |        |
| 14026A   | 4026W2A016A | Locker                                 | R   |             |        |
| 14970A   | 4970WRA001B | Spring                                 | R   |             |        |
| 15006A   | 5006W3A012A | Cap,Choke Cover                        | R   |             |        |
| 23506A   | MFM41152302 | Membrane                               | R   |             |        |
| 23551A   | AGM36115302 | Parts Assembly(Panel,Control+Membrane) | R   |             |        |
| 23572A   | MGC39841502 | Panel,Control                          | R   |             |        |
| 24510L   | 4510W3L003B | Lever                                  | R   |             |        |
| 24781M   | ACM35638502 | Controller Assembly,Keypad             | R   |             |        |
| 24970A   | 4B72023B    | Spring                                 | R   |             |        |
| 250201   | MBG39841602 | Button                                 | R   |             |        |
| 268711   | 6871W1S197P | PCB Assembly,Sub                       | R   |             |        |
| 33052A   | 3052W2A021A | Cover,Resin                            | R   |             |        |
| 33112U   | 3112W1U037K | Case,U Bending                         | R   |             |        |
| 33390G   | 3390W1A027A | Tray,Glass                             | R   |             |        |
| 34370T   | 4370W1A006B | Shaft,Turntable                        | R   |             |        |
| 34930W   | 4930W3B029A | Holder,Wire                            | R   |             |        |
| 35012A   | 5012W3A020C | Insulator                              | R   |             |        |
| 35889A   | 5889W2A015K | Turntable Assembly                     | R   |             |        |
| 36549S   | 6549W1S011W | Motor, AC Synchronous                  | R   | 6549W1S017J |        |
| 43500A   | 3500W1A018A | Holder,Locker                          | R   |             |        |
| 43501A   | 3501W1A053A | Holder Assembly,Locker                 | R   |             |        |
| 466001   | 6600W1K001D | Switch,Micro                           | R   |             |        |
| 466003   | 6600W1K001C | Switch,Micro                           | R   |             |        |
| 50CZZH   | 0CZZW1H004C | Capacitor,High Voltage                 | R   | 0CZZW1H004P |        |
| 50CZZH   | 0CZZW1H004C | Capacitor,High Voltage                 | R   | 0CZZW1H005A |        |
| 50FZZA   | 3B74133Q    | Fuse,Time Delay                        | R   | 3B74133K    |        |
| 54810C   | 4810W4C003B | Bracket,Capacitor                      | R   |             |        |
| 54974S   | 4974W0A003C | Guide,Suction                          | R   |             |        |
| 54974T   | 5208W1A012B | Duct                                   | R   |             |        |
| 54980A   | 4980W3A038A | Supporter                              | R   |             |        |
| 55262A   | 5208W1A017A | Duct                                   | R   |             |        |
| 55900A   | 5900W1A007B | Fan                                    | R   |             |        |
| 56170D   | 6170W1D077J | Transformer,high voltage               | R   | 6170W1D112D |        |
| 56201A   | 6201W1A014A | Filter Assembly,Noise                  | R   | 6201W1A014B |        |
| 56201A   | 6201W1A014A | Filter Assembly,Noise                  | R   | 6201W1A014E |        |
| 56201A   | 6201W1A014A | Filter Assembly,Noise                  | R   | 2B72130M    |        |
| 56324A   | 6324W1A001L | Magnetron                              | R   | 6324W1A001B |        |
| 56411A   | 6411W1A019V | Power Cord Assembly                    | R   | 6411W1A019W |        |
| 56411A   | 6411W1A019V | Power Cord Assembly                    | R   | 6411W1A019X |        |
| 56501A   | 6501W1A006A | Sensor Assembly                        | R   |             |        |

| LOC. NO. | PART NO.    | DESCRIPTION         | SVC | ALTERNATE   | REMARK |
|----------|-------------|---------------------|-----|-------------|--------|
| 56549F   | 6549W1F009C | Motor,AC Fan        | R   |             |        |
| 56851D   | 6851W1A002D | Cable,Assembly      | R   | 6851W1A002E |        |
| 568771   | 6877W1A506E | Harness,Single      | R   |             |        |
| 56912B   | 6912W3B002L | Lamp,Incandescent   | R   |             |        |
| 56930V   | 6930W1A001L | Thermostat          | R   | 6930W1A001C |        |
| 56930V   | 6930W1A001L | Thermostat          | R   | 6930W1A004N |        |
| 63302A   | 3302W0A036B | Plate,Base          | R   |             |        |
| 63303A   | 3303W0A019B | Plate Assembly,Base | R   |             |        |
| 65006B   | 5006W3A019A | Cap,Base Plate      | R   |             |        |
| 948501   | 3B72244T    | Damper              | R   |             |        |
| WEB001   | 1EBF0402494 | Screw,Taptite       | R   |             |        |
| WSZ002   | 1SBF0402418 | Screw,Taptite       | R   |             |        |
| WSZ062   | 4000W4A003A | Screw,Customized    | R   |             |        |
| WSZ085   | 4B70188C    | Screw,Customized    | R   |             |        |
| WSZ185   | 1SZZW2A002A | Screw,Customized    | R   |             |        |
| WTP004   | 1TPL0302418 | Screw,Tapping       | R   |             |        |
| WTP013   | 1TPL0402418 | Screw,Tapping       | R   |             |        |
| WTT010   | 1TTG0402422 | Screw,Tapping       | R   |             |        |
| WTT021   | 1TTL0402418 | Screw,Tapping       | R   |             |        |
| WTT028   | 1TTL0402818 | Screw,Tapping       | R   |             |        |
| WTT037   | 1TTL0403818 | Screw,Tapping       | R   |             |        |