





OVEN PARTS

For Models: KBMC140HBL03, KBMC140HWH03, KBMC140HBT03, KBMC140HSS03
(BLACK) (WHITE) (BISCUIT) (STAINLESS)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT4455988	Installation Instructions
	LIT8300890	Use & Care Guide
	LIT4450786	Cook Guide Label
	LIT4451052	Guide—Easy Use M/W
	LIT8302335	Tech Sheet
	LIT4449264	Easy Set Guide
	LIT3191638	Safer Cooking Tips
2		Trim, Side
	4452624	RH Black
	4452626	RH White
	4452971	RH Biscuit
	4452556	RH Stainless
	4452625	LH Black
	4452627	LH White
	4452972	LH Biscuit
	4452557	LH Stainless
3	4451605	Cap, Spacer
4		Rail, Side
	4456545	Right Side
	4456546	Left Side
5	4452559	Side, Chassis (R.H. & L.H.)
6	4456487	Base, Chassis
7		Trim, Bottom
	4456540	Black
	4456542	White
	4456544	Biscuit
	4456538	Stainless
8	4452554	Chassis, Back
9	4449906	Extension Filler
10	3400832	Screw
11	4449809	Screw
12	4452492	Insulation—Grill
13	4452491	Insulation—Top
14	4455475	Bracket
15	4455471	Spacer
16	4455476	Bracket

CONTROL PANEL PARTS

For Models: KBMC140HBL03, KBMC140HWH03, KBMC140HBT03, KBMC140HSS03
(BLACK) (WHITE) (BISCUIT) (STAINLESS)




Illus. No.	Part No.	DESCRIPTION
1	4452604	Panel, Control Black
	4452605	White
	4452974	Biscuit
	4451791	Stainless
2	4453423	Switch, Membrane Black
	4453424	White
	4453426	Biscuit
	4453420	Stainless
3	4452248	Insulator, Board
4	4452249	Insulator, Board Support
6	4452345	Insulator, Dielectric
7	8302345	Assy, Control
8	3400406	Screw
9	3400832	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE COMPARTMENT PARTS

For Models: KBMC140HBL03, KBMC140HWH03, KBMC140HBT03, KBMC140HSS03
(BLACK) (WHITE) (BISCUIT) (STAINLESS)




Illus. No.	Part No.	DESCRIPTION
5	4456399	Support Rails
11	4452548	Rear Channel
12	4449809	Screw
13	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS

For Models: KBMC140HBL03, KBMC140HWH03, KBMC140HBT03, KBMC140HSS03
(BLACK) (WHITE) (BISCUIT) (STAINLESS)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS

For Models: KBMC140HBL03, KBMC140HWH03, KBMC140HBT03, KBMC140HSS03

(BLACK)

(WHITE)

(BISCUIT)


(STAINLESS)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4375437	Bracket, Capacitor	28	4375231	Block, Fuse	53	4375426	Air Bleed
3	4375252	Rubber Ring	29	4375278	Motor, Blower	54	4375439	Shield, Heat
4	4375038	Screw	30	4375279	Thermostat			Right
5	4375314	Air Duct, Magnetron	31	4375423	Thermostat	55	4375422	Sensor, Temp.
6	4375253	Support, Tube	32	4375281	Thermostat	56	4375420	Insulation
7	4375421	Plug, Ceramic	33	4375408	Q Tube Assembly	57	4375419	Duct, Heater
8	4375255	Bushing	34	4375438	Transformer	58	4375416	Washer
9	4375256	Reflector	35	4375406	Ring, Turntable	59	4375417	Element, Heater
10	4375257	Chamber, Reflector	36	4375407	Shaft, Turntable	60	4375418	Fan
12	4375450	Duct, Inlet	39		Bracket, Hinge	61	4375429	Motor, Fan
13	4375316	Insulation, Switch		4375412	Left	62		Left-Threaded Nut
14	4375322	Fan Wheel		4375413	Right			Serviced With
15	4375317	Duct, Air	42	4375331	Plate, Grill			Motor Item 61
16	4375415	Block, Slide	43	4375332	Bracket	63	4375430	Thermostat
17	4375248	Cover Plate, Upper	44	4375441	Fan Cap	64	4375431	Shield, Heat
18	4375251	Screw	46		Switch Holder	65	4375432	Insulation
19	4375318	Lens, Lamp		4375412	Left	66	4375433	Chamber, Heat
20	4375319	Spring		4375413	Right	67	4375437	Isolation Plate
21	4375320	Reflector	47	4375258	Nut	68	4375338	Cover Plate
22	4393900	Pan Handle	48		Insulation	71		Side Plate
23	4452220	Rack		4375409	Left Side		4375341	Left
24	4393536	Crisp Plate		4375410	Right Side		4375342	Right
25	4375436	Capacitor	49	4375411	Plate, Side	72	4375405	Turntable
26	4375424	Magnetron			Bottom	73	4375346	Switch
27	4375321	Fuse	50	4375425	Valve	74	4375347	Motor, Turntable
			51	4375428	Screw To Valve	75	4375348	Lamp
			52	4375427	Thermoactuator	76	4375349	Rectifier
						77	4375435	Cable

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KBMC140HBL03, KBMC140HWH03, KBMC140HBT03, KBMC140HSS03
(BLACK) (WHITE) (BISCUIT) (STAINLESS)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4450378	Cover, Top	8	4449964	Grommet	19	4455038	Transformer-Cntrl Control
2	4448935	Baffle, Blower	11	4449868	Block, Terminal	20	4452247	Cover, Plate
3	4450920	Blower	13	4456145	Vent-Cntrl Panel	21	4449809	Screw
4	4451789	Plate, Mounting	14		Side, Control Top	23	112432	Nut
5	6610122	Transformer, (Lights)		4451597	Right	24	1180485	Screw
6	4451634	Exhaust Duct		4451598	Left	25	4451934	Suppressor
7	4450027	Bracket, Duct	15	4452244	Back, Control	26	3400080	Screw
			16	4450551	Cover, Top Rear	27	4450118	Nut
			17	4448664	Clamp			
			18	4450554	Cover, Top Front			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE DOOR PARTS

For Models: KBMC140HBL03, KBMC140HWH03, KBMC140HBT03, KBMC140HSS03
(BLACK) (WHITE) (BISCUIT) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
1	4448937	Glass, Middle
2	4450946	Frame, Door
4	4449141	Bracket, Mounting
	4449142	Right Side
	4449142	Left Side
5	4449083	Filler, Side
	4449086	Right Side
	4449086	Left Side
6	4452502	Handle, Door
	4452503	Black
	4452503	White
	4452871	Biscuit
	4452088	Stainless

Illus. No.	Part No.	DESCRIPTION
7	4452211	Glass, Outer
	4452789	Black
	4452995	White
	4452259	Biscuit
	4452259	Stainless
8	4451055	Spacer (Stainless)
9	4452331	Bracket, Handle
10	4450863	Retainer, Glass-Clip
	4450864	Black
	4450864	White
	4452119	Biscuit
	4451432	Stainless
11	4375339	Door, Plate
12	4375414	Frame, Inner

Illus. No.	Part No.	DESCRIPTION
13	4375330	Strap, Door
14	4375313	Screw
15	4375323	Hinge, Door
	4375323	Left
	4375324	Right
16	4451009	Spring, Torsion
	4452396	BI/Wh/Bt Model
	4452396	Stainless Model
18	4449809	Screw
19	4449040	Screw
20	4450038	Screw
21	4451040	Screw
	4451040	BI/Wh/Bt Model
	3196184	Stainless Model

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KBMC140HBL03, KBMC140HWH03, KBMC140HBT03, KBMC140HSS03
(BLACK) (WHITE) (BISCUIT) (STAINLESS)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

FOLLOWING PARTS NOT ILLUSTRATED

482338 Sealer, Silastic
(3 oz.)

WIRING HARNESS PARTS

4453215 Harness, Main
4450831 Wire, Ground
4450800 Screw, Ground
4450950 Conduit, Combo
4448950 Screw, Install (4)
4452400 Lead, Ground Strap

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST