




48" BUILT IN REFRIGERATOR

MODELS:

KBSD608EBS01 (Black Stainless Steel)

KBSD608ESS01 (Stainless Steel)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15	3400230	Screw	36	2006617	Bracket, Base Support (Rear)
	W10763009	Use and Care Guide	16	2257644	Hinge, Top	37	2006346	Washer, Extension Arm
	W10763005	Energy Guide	17	W10674648	Bracket, Filter	38	2208136	Clip, Water Tube
		Tech Sheet	18	W10001250	Screw	39	2320601	Shield, Water Valve
	W10910733	English	19	2004994	Lock, Bushing	40	W10271541	Connector, Union
	W10910734	French	20	W10484913	Bushing, Top Hinge	41	8281163	Screw (Stainless)
	W10763010	Installation Instructions	21	W10663352	Clip	42	1118894	Switch, Rocker Arm
	W10762997	Wiring Diagram	22	2221242	Spring, Door Closure (Green)		1115373	Switch, Rocker Arm (Freezer)
2		Cabinet (Not A Serviceable Part)	23	486194	Screw	43	2215938	Cover, Switch
3		Button, Water Filter	24	2005008	Ring, Bushing Retaining	44	487415	Screw
	2260503B	Black	25	W10279391	Assembly, Smart Valve Wire	45		Bracket, Switch
4	W10138054	Assembly, Roller	26	W10482554	Cover, Bottom Gap		W10741112	Left Hand
5		Assembly, Support Base	27		Hinge, Bottom		W10741111	Right Hand
	W10279275	Left Hand		2006779	Left Hand	46	2215612	Cover, Air Duct
	W10138423	Right Hand		2006780	Right Hand	47	2005032	Leveler, Adjustable
6		Cap, Water Filter	28	2302876	Bushing, Adjustable	48	2006841	Ring, Retainer
	W10797527	Black	29	8533913	Screw	49		Assembly, Cam
7	2307640	Bracket, Grill Mounting	30	W10188551	Skirt, Bottom Grille		W10121046	Left Hand
8	2307584	Grommet, Crossover Tube	31	W10357286	Fitting, Water		2307857	Right Hand
			32		Grille, Bottom	50	W10780213	Assembly, Switch Wire
9	2005433	Spacer		W10182718	Black	51	W10683737	Tube, Filter Outlet
10	W10121140	Housing, Water Filter	33	2320559	Support, Valve	52	W10296807	Tube, Filter Inlet
11	2318189	Tray, Filter Drip	34		Bracket, Support Base (Front)	53	W10820321	Valve, Inlet
12	3400525	Screw		2006616	Left Hand			
13	W10754687	Filter, Water		2006556	Right Hand			
14	489399	Screw	35	1157158	Screw			


CABINET TRIM PARTS



CABINET TRIM PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Cabinet Side (Right)	4	2005925	Seal, Side Trim	6		Trim, Cabinet Side (Left)
	W10568005	Aluminum	5		Trim, Top Cabinet		W10568007	Aluminum
2	486194	Screw		2314018	Aluminum			
3	W10121451	Insert, Blind Threaded						


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	12	2310205	Assembly, Meat Pan Wire	23	W10159488	Diverter, Crisper Cover
2	2306010	Thermistor	13	8533929	Screw (Stainless)	24	2259398	Seal, Air Duct
3	2208970	Duct, Air	14	486194	Screw	25	2003577	Guard, Air Return
4	2259077	Ladder, Shelf	15	2221296	Assembly, Air Baffle	26	W10843339	Assembly, LED Module
5	520965	Support, Ladder	16	W10645131	Reservoir, Water	27	W10475008	Seal, Air Duct (Round Hole)
6	W10808292	Screw	17	W10141518	Screw			
7	487539	Screw (Stainless)	18	2309222	Assembly, Air Diffuser			
8	2302937	Thermistor	19	2317105	Cover, Thermistor			
9	2302986	Lid, Baffle	20	2188820	Thermistor			
10	W10169528	Assembly, Control Baffle	21	W10475010	Assembly, Spacer			
11	2317844	Assembly, Thermistor	22	2309087	Cover, Air Diffuser			


FREEZER LINER AND AIR FLOW PARTS



FREEZER LINER AND AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10436861	Motor, Fan	18		Block, Fan Scroll	32	2220904	Gasket, Evaporator Cover
2	2198665	Tube, Circuit Board		2209066	Left Hand	33	2259493	Cover, Receiver
3	2169142	Blade, Fan		2209482	Right Hand	34	W10482187	Harness, Bi-Metal Wire
4	W10260421	Retainer, Fan Motor	19	2215650	Cover, Emitter	35	2306010	Thermistor
5	2302817	Gasket, Scroll Assembly	20		Liner (Not A Serviceable Part)	36	2317105	Cover, Thermistor
6	W10321090	Grommet, Motor	21	2259025	Cover, Air Outlet	37	W10808292	Screw
7	486194	Screw	22	W10813095	Assembly, Evaporator Cover	38	2259032	Ladder, Shelf
8		Wedge, Air Duct	23	2169104	Sealer, Insulation	39	2259445	Support, Ladder
	2259464	Right Hand	24	2302851	Support, Air Duct	40	2198634	Pin, Door
9	2317844	Assembly, Thermistor	25	487539	Screw (Stainless)	41	W10193840	Board, Emitter Circuit
10	W10843339	Assembly, LED Module	26	2198635	Spring, Door	42	2198633	Flipper, Shut Off
11	2221070	Clamp, Tube	27	2309284	Deflector, Air Duct	43	2255563	Slide, Icemaker Shut Off
12	W10581989	Gasket, Evaporator Cover	28	1112260	Support, Evaporator	44	W10290817	Board, Receiver Circuit
13	489214	Screw	29	W10173127	Assembly, Shelf Stud	45	W10160570	Bi-Metal, Defrost
14	2182120	Scroll, Fan	30	W10191952	Screw	46	W10142283	Screw (White)
15		Wedge, Air Duct	31		Rail, Evaporator Cover			
	2259465	Left Hand		2221107	Left Hand			
16	2307775	Duct, Air		2259355	Right Hand			
17	2198643	Lens, Receiver						

ICEMAKER AND ICE CONTAINER PARTS



ICEMAKER AND ICE CONTAINER PARTS

Illus.
No. Part No. Description

1	2222970	Bin, Ice
2	W10769145	Assembly, Ice Container
3	W10749207	Button, Bin
4	W10134785	Latch, Bin
5	2198608	Spring, Latch
6	2198671	Screw (Stainless)
7	8281163	Screw (Stainless)
8	2188919	Clip, Shaft


Illus.
No. Part No. Description

9	2198628	Seal
10	2318082	Shaft, Drive
11	2318011	Enclosure, Motor
12	2315547	Motor, Dispenser
13	2318028	Cover
14	2315559	Sleeve, Bearing
15	W10254073	Washer
16	W10774434	Assembly, Icemaker
17	2252228	Bracket, Icemaker Mounting

Illus.
No. Part No. Description

18	W10289690	Cover, Icemaker
19	W10508659	Assembly, Icemaker Wire


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798005	Assembly, Control Box	4	W10780415	Bracket, Control Box	6	487539	Screw (Stainless)
2	2317000	Clip, Control Box	5	W10142283	Screw (White)	7	W10760791	Assembly, User Interface
3	W10458299	Wire, Jumper						


REFRIGERATOR SHELF PARTS



REFRIGERATOR SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10568585	Assembly, Fixed Shelf	7	2256249	Front, Crisper Pan	11	8533928	Screw
2	W10701859	Rack, Wine	8		Spacer, Crisper			Left Hand
3	W10556313	Assembly, Meat Pan Cover		2256223	Left Hand		8533929	Screw (Stainless)
				2256222	Right Hand			Right Hand
4	W10556776	Assembly, Crisper Cover	9		Slide, Crisper	12	W10407628	Assembly, Meat Pan
				2302956	Left Hand	13	2256367	Assembly, Pan Front
5	W10407625	Assembly, Crisper Pan		2302957	Right Hand			
6		Slide, Meat Pan	10		Spacer, Meat Pan	14	W10826105	Assembly, Produce Preserver
	2302954	Left Hand		2256243	Left Hand			
	2302955	Right Hand		2256244	Right Hand			


FREEZER SHELF PARTS



FREEZER SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10759087	Shelf, Wire	5		Slide, Basket	7	2198641	Bracket, Icemaker Cover
2	W10759067	Shelf, Fixed		2259318	Left Hand			
3	2259083	Basket, Freezer		2259317	Right Hand	8	W10504754	Cover, Icemaker
4	2256271	Assembly, Basket Front	6	8533928	Screw			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10761879	Door, Refrigerator	9		Gasket, Door	15	W10761897	Spacer, Door Skin (Top)
2	W10127710	Plate, Handle Door		W10760886	Grey	16	308544	Screw
3	W10485980	Assembly, Hinge (Top)	10		Skin, Door	17	W10756209	Spacer, Hinge Side Door
4	2316804	Spacer, Door Hinge Bottom		W10756465	Black Stainless	18	W10761937	Spacer, Door Skin (Bottom)
5	W10162602	Screw	11	W10756464	Stainless	19	W10323748	Bin, Gallon Door
6	2302878	Assembly, Hinge (Bottom)		W10541592	Stainless	20	W10127980	Filler, Foam Board
7	W10798552	Assembly, Utility Bin	12	W10758113	Spacer, Handle Side Door			
8	W10323600	Bin, Shallow Door	13	488568	Screw (Stainless)			
			14	8281252	Screw (Black)			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10761945	Door, Freezer	7		Door, Handle	13	W10758123	Spacer, Door Skin Bottom
2	2302879	Assembly, Hinge (Bottom)		W10541592	Stainless	14	W10756209	Spacer, Hinge Side Door
3	W10162602	Screw	8	W10758113	Spacer, Handle Side Door	15	308544	Screw
4	W10485980	Assembly, Hinge (Top)	9		Skin, Door	16	W10159586	Filler, Top Foam Board
5	2316804	Spacer, Door Hinge Bottom		W10756223	Black Stainless		W10159583	Filler, Bottom Foam Board
6		Gasket, Door		W10756222	Stainless	17	W10127710	Plate, Handle Door
	W10760884	Grey	10	8281252	Screw (Black)	18	W10323603	Bin, Shallow
			11	W10758121	Spacer, Door Skin (Top)			
			12	488568	Screw (Stainless)			


DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	11		Housing, Middle (Not Available Order Item 12)	15	2305219	Cover, Control
2	486194	Screw				16	2321746	Assembly, User Interface Control Cover
3	W10542660	Bracket, Motor	12	W10260622	Assembly, Housing	17	W10151236	Assembly, User Interface
4	W10546285	Assembly, Motor and Bracket			KBSD608EBS01			
5	W10205979	Motor, Ice Door		W10260620	Housing Assembly	18		Tray, Housing
6	W10504458	Door, Ice			KBSD608ESS01		2318062B	Black
7	W10542663	Support, Ice Door	13		Assembly, Water Paddle		2318062US	Universal Silver
8	4449745	Screw		2305307GN	Universal Silver	19	2305342	Assembly, LED
9	2305235	Assembly, Spigot	14		Assembly, Ice Paddle	20	2305447	Clip, Wiring
10	2318017	Assembly, Separator		2305306GN	Universal Silver			


TOP GRILLE AND UNIT COVER PARTS



TOP GRILLE AND UNIT COVER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Top Grille	6		Nameplate	7	W10645086	Divider, Unit Air
	W10761970	Black Stainless		W10518672	Grey	8	2215910	Grommet, Flexible
	W10761969	Stainless						
2	W10545068	Cover, Unit						
3	486194	Screw						
4	2256466	Panel, Unit Back						
5	W10694109	Cover, Unit Front						


UPPER UNIT PARTS



UPPER UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10645666	Assembly, Inverter Box	17	W10624574	Supply, Power	34	W10321055	Bracket, Control Assembly
2	489373	Screw	18	W10770059	Plate, Circuit Board (Top)	35	549193	Clamp, Power Cord
3	W10913755	Compressor	19	2310195	Assembly, Jumper Wire (Power Switch to Power Cord)	36	2266802	Switch, Power Disconnect
4	W10550831	Housing, Control Board Mounting	20	2155774	Tie, Wire	37	2319835	Grommet, Condenser
5	2318054	Control, Electronic	21	W10175593	Drier	38	W10775849	Assembly, Unit Wire
6	1100826	Grommet	22	W10414681	Bracket, Fan Motor	39	W10761479	Plate, Circuit Board
7		Support, Condenser	23	W10527155	Motor, Condenser Fan			FOLLOWING PARTS NOT ILLUSTRATED
	W10525177	Left Hand	24	W10139483	Blade, Fan		978025	Valve, Access
	W10525179	Right Hand	25	W10415670	Orifice, Fan		978026	Valve, Access
8	W10625009	Tube, Heat Loop Transition	26	W10146359	Screw		978027	Valve, Access
9	2215676	Cover, Terminal	27	W10790783	Supply, LED Power		978028	Valve, Access
10	W10587113	Grommet	28	2259350	Board, Power Supply		978029	Valve, Access
11	W10200659	Control, Electronic	29	W10624944	Tube, Drier Transition		978030	Valve, Access
12	2203075	Spacer	30	W10528578	Tube, Process		876764	Valve, Access
13	2256328	Bracket, Inverter Mounting	31	486194	Screw			REFRIGERANT CHARGE
14	487539	Screw (Stainless)	32	W10525175	Cover, Condenser Support			7.25 oz. (R-134A)
15	1157158	Screw	33	2310196	Cord, Power			
16	W10591457	Condenser						

LOWER UNIT AND TUBE PARTS



LOWER UNIT AND TUBE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10139908	Cover, Evaporator Seal	9	W10499597	Tube, Discharge	19	W10413009	Grommet, Air Return
2	486194	Screw	10	2188820	Thermistor	20	2215648	Dampener
3	W10157752	Bracket, Heater	11	W10427993	Evaporator	21	W10160981	Assembly, Air Return Bracket
4	W10648568	Tube, Oil Trap Suction	12	W10140162	Heater, Defrost	22	W10580754	Block, Evaporator Side
5	W10388653	Tube, Transition (Drier/Restrictor)	13	1113048	Clamp, Heater	23	W10686115	Seal, Return Air
6	W10281063	Assembly, Drain Pan	14	W10321050	Shelf, Wiring Cover			
7	W10309012	Cover, Wiring	15	W10432308	Gasket, Evaporator			
8	W10321048	Cover, Wire Box	16	4389107	Tie, Wire			
			17	W10169509	Clip, Heat Exchanger			
			18	2320554	Support, Drain Pan			