




REFRIGERATOR

MODELS:

KFIS29PBMS00 (Monochromatic Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15		Hinge, Center	30	W10523222	Cover, Unit
	W10568022	Tech Sheet		W10248706	Grey	31	M0108107	Clamp, Tube
	W10417002	Use and Care Guide			(Left Hand)	32	W10455336	Waterline, Customer Connection
	W10446589	Energy Guide		W10248703	Grey	33	W10491298	Tube, Drain
					(Right Hand)	34	W10505294	Coupler, Door
2	W10453401	Supply, Power	16	W10336736	Cover, Roller	35	W10212137	Retainer, Door
3	W10344432	Block, Pivot	17		Cover, Corner	36		Cabinet (Not a Servicable Part)
4	W10505487	Gasket		12587703AP	Grey	37	W10271541	Connector, Union
5	W10581605	Board, Control	18	W10455331	Valve, Smart	38	549193	Clamp, Power Cord
6	W10415341	Gasket, HV Box	19		Assembly, Roller	39	W10141645	Screw
7	A3076901	Plug, Button		W10515763	Left Hand	40	12990302	Screw
8	W10141622	Brake, Roller		W10515762	Right Hand	41	W10277839	Lid, HV
9	12992602	Screw	20	12991302	Screw	42	W10455337	Tube, Water
10		Hinge, Top	21	12990701	Screw			
	W10248410	Left Hand	22		Grille, Toe			
	W10248409	Right Hand		W10637671	Grey			
11	W10403212	Screw (Grey)	23	12992601	Screw			
12		Cover, Right Hand Hinge	24	W10455330	Cover, Valve			
	W10407158	Grey	25	W10141645	Screw			
13		Cover, Left Hand Hinge	26	12990511	Screw			
	W10471618	Grey	27	W10421948	Supply, LED Power			
14	W10308751	Screw (Black)	28	W10485658	Cover, Control Box			
			29	12466105	Switch, Light			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	15	12990518	Screw	29	W10389152	Support, Fan
2	W10657942	Housing, Water System	16	W10598013	Cover, Icebox	30	W10635022	Adapter, Icebox
3	W10482107	Tube, Fill	17	W10492817	Assembly, Icebox (Foamed)	31	W10389154	Retainer, Damper
4	W10394084	Reservoir, Water (Also Order Wire Tie Part 8567668 Qty. 5)	18	W10469927	Enclosure, Evaporator	32	W10389149	Support, Damper
5	W10341329	Valve, Dual Water	19	W10537710	Pan, Drain	33	W10248595	Damper, Electronic Control
6	W10238156	Housing, Water Filter	20	W10505516	Trim, Icebox	34	W10438957	Cover, Thermistor
7	W10279854	Enclosure, Valve	21	W10460280	Fan, Icebox	35	W10501260	Cover, Evaporator
8	W10488685	Cover, Water	22	W10503454	Assembly, Evaporator	36	W10392172	Gasket, Fan
9	2223877	Latch, Push	23	W10637153	Assembly, LED Light Module	37	W10280988	Gasket, Rear Supply
10	W10277949	Door, Filter Access	24	W10395278	Motor, Fan (Also Order Fan Support #W10389152)	38	W10320706	Gasket, Rear Return
11	W10609378	Filter, Water	25	W10553630	Assembly, Fascia (Includes Heater)			Following Parts Not Illustrated
12	W10315189	Filter, Air	26	C3680310V	Switch, Light	W10570599		Harness, Dual Valve
13	W10515793	Waterline, Valve to Hinge	27	W10434481	Bracket, Reservoir	W10761050		Harness, Refrigerator Lights
14	W10554299	Heater, Fill Tube	28	W10280983	Insulation			


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	8	12990504	Screw	14	W10503218	Assembly, Drain Funnel
2	A3189392	Gasket, Foam	9	W10496613	Grille, Air (Freezer)	15	M0500703	Seal
3	W10637153	Assembly, LED Light Module	10	W10363507	Shroud, Evaporator Fan	16	B8381501	Gasket, Drain
4	W10513424	Cover, Evaporator	11	12986101	Blade, Fan	17	W10405166	Cover, Thermistor
5	12990511	Screw	12	12951101	Grommet, Fan Motor	18	W10531268	Gasket, Dual Evaporator
6	12956601	Clip, Fan Motor	13	W10514110	Motor, Evaporator (Includes Harness, Thermistor, and Defrost Thermostat)	19	W10280385	Thermistor
7	C3680310V	Switch, Light						


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Left	11		Nameplate	24	W10400825	Retainer, Ice Chute
	W10341416	Stainless		W10427988	Grey	25	W10347087	Gasket, Ice Chute
2		Door, Right	12	W10460893	Screw	26	W10646855	Vent, Thermistor
	W10341284	Stainless	13	W10468069	Trivet, 2 Liter	27	W10248856	Bucket, Gallon
3	W10464016	Screw	14	W10447153	Frame, Bin	28		Gasket, Door
4	W10549590	Door, Ice	15	489214	Screw		W10407146	Grey
5		Latch, Door	16	W10347085	Gasket, Ice Compartment Door	29	W10258520	Door, Emitter
	W10355634	Left Hand	17	W10245516	Clip, Tube	30	2198635	Spring, Door
	W10372267	Right Hand	18	W10518658	Board, Receiver Circuit	31	2198634	Pin, Door
6		Mullion, Door	19	W10258510	Cover, Receiver	32	W10515780	Tube, Water
	W10654762	Grey	20	3400065	Screw (Stainless)	33	W10010140	Set Screw (Silver)
7	12990204	Screw	21	W10258502	Cover, Emitter			
8		Handle, Door	22	W10258540	Slide, Icemaker Shut Off			
	W10557401	Stainless	23	W10518659	Board, Emitter Circuit			
9	12990504	Screw						
10		Bumper, Door						
	W10407188	Grey						


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer	8	W10493159	Assembly, Center Pan	16		Stop, Pan
	W10341279	Stainless	9	W10248509	Clip, Shaft		W10485096	Left Hand
2		Handle, Door	10	W10507444	Divider, Lower		W10485089	Right Hand
	W10557406	Brushed Aluminum	11		Gasket, Door	17	W10287054	Screw, Set
3	W10460893	Screw		W10248749	Grey			
4	W10503522	Shaft	12		Assembly, Adapter			
5		Assembly, Bracket		W10619219	Left Hand			
	W10638293	Left Hand		W10619218	Right Hand			
	W10638294	Right Hand	13	W10493168	Assembly, Upper Pan			
6	W10594047	Assembly, Lower Pan	14	W10469177	Support, Pan			
7	12990518	Screw	15	489443	Screw (Stainless)			


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10494227	Cord, Power	20	W10608485	Assembly, Evaporator and Heater	36	W10413009	Grommet, Air Return
2	12825802	Blade, Fan						Following Parts Not Illustrated
3	W10570074	Baseplate	21	W10364560	Coil, 3 Way Valve			
4	12990511	Screw	22	2188874	Motor, Condenser	978025		Valve, Access (1/4")
5	W10547687	Extension, Drain	23	10428101	Clip, Heater	978026		Valve, Access (5/16")
6	W10391081	Assembly, Valve Body	24	W10494224	Harness, Unit	978027		Valve, Access (3/8")
7	W10303521	Sleeve	25	W10286069	Drier	978029		Valve, Access (5/8")
8	W10238584	Tray, Evaporator	26	W10168473	Compressor	978030		Valve, Access (3/4")
9	W10622701	Screw	27	W10142294	Screw	876764		Valve, Access (3/16")
10	12729128	Heater, Defrost	28	12477202	Axle, Roller			REFRIGERANT CHARGE
11	W10186719	Assembly, Inverter Box	29	W10406719	Shroud			49 grams (R600a)
			30	W10626970	Assembly, Suction Tube			
12	W10248621	Clip, Condenser	31	W10278140	Cover, Condenser (Bottom)			
13	12477102	Roller	32	W10296661	Clip, Bottom Cover			
14	12992101	Screw	33	W10491355	Gasket, Airdam			
15	10835903SP	Grommet, Compressor	34	W10236396	Strap, Compressor			
16	W10627646	Assembly, Condenser	35	W10514110	Motor, Evaporator (Includes Harness, Thermistor, and Defrost Thermostat)			
17	W10391376	Bracket, Valve						
18	W10342573	Tray, Drip						
19	W10141625	Screw						

SHELF PARTS



SHELF PARTS

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10510429	Front, Pantry
2	W10530317	Plate, Slide Center
3	W10489978	Support, Pantry
4	W10467461	Ladder, Center
5	W10248799	Glass, Pantry
6	W10342618	Heater, Pantry
7	W10397313	Pan, Crisper
8	W10673458	Shelf, Fixed
9	W10550026	Front, Crisper
10	W10514690	Pan, Pantry
11	W10493521	Shelf, Full
12	W10467369	Divider, Pantry
13	W10372170	Ladder, Side
14	W10248578	Glass, Crisper
15	W10316419	Cover, Crisper
16	W10530315	Support, Crisper
17	W10248524	Pan, Crisper


Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
18		Plate, Side Pantry
	W10248834	Left Hand
	W10317523	Right Hand
19		Slide, Pantry
	W10248531	Left Hand
	W10248532	Right Hand
20	W10432697	Insulation, Sideplate
21		Plate, Crisper
	W10530318	Left Hand
	W10530306	Right Hand
22	W10530316	Plate, Side
23	W10467415	Plate, Crisper Front
24	W10530307	Track, Center
25	W10248819	Slide, Crisper
26	12990518	Screw
27	W10236512	Support, Front

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
28	W10423560	Screw
29	W10408747	Holder, Filter
30	W10346771	Filter, Produce Preserver
31	W10584145	Cover, Front (Includes LED Assembly)
32	W10248837	Cover, Top
33	W10565995	Assembly, User Interface
34	W10539187	Harness, Wire (Includes Thermistor)
35	12990204	Screw
36	W10490266	Support, Pantry Cover (Includes Gasket)
37	W10467416	Plate, Pantry Front
38	W10413979	Rack, Wine



DISPENSER FRONT PARTS



DISPENSER FRONT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	5	W10347634	Assembly, Separator	11	W10542708	Grate, Drip Tray
2		Assembly, User Interface	6	W10317267	Spigot	12	W10238083	Assembly, LED
	W10559673	Stainless	7	W10347633	Assembly, Ice Door			
3		Wall, Dispenser False	8		Insert, Drip Tray			
	W10486346	Grey		W10402269	Grey			
4		Assembly, Pad	9	W10435760	Guide, Ice			
	W10346924	Grey	10		Tray, Dispenser			
				W10400887	Grey			


MOTOR AND ICE CONTAINER PARTS



MOTOR AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10272364	Screw	4	W10347120	Clip, Retainer	7	8281163	Screw (Stainless)
2	W10347055	Plate, Ice Chute	5	W10347114	Shaft, Motor	8	W10347093	Assembly, Ice Container
3	2198628	Seal	6	W10215646	Motor, Dispenser			

ICEMAKER PARTS



ICEMAKER PARTS

<u>Illus.</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10498261	Assembly, Icemaker	

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	W10134625	Apollo Grey
	W10917540	Midnight Grey
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key