




30" ELECTRIC FREESTANDING RANGE

MODELS:

AER6603SFS2 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5	W10275048	Element (3000/1400W)	8	W10306542	Bracket, Anti-Tip
	W11047681	Instructions, Installation			(Left Front)	9	7101P485-60	Screw, Anti-Tip Kit
	W10866293	Guide, Use and Care		8273994	Element (1200W) (Left Rear and Right Front)			FOLLOWING PARTS NOT ILLUSTRATED
	W10842026	Sheet, Tech		8273993	Element (1800W) (Right Rear)		W11171889	Harness, Wire (Main)
2	W10225448	Spring, Element					W11134551	Harness, Cooktop (Right)
3	W10691223	Pan, Radiant Element					W11134603	Harness, Cooktop (Left)
4		Cooktop	6	3196169	Screw			
	W10853125	Black	7	W10607641	Bracket, Cooktop (Left)			
				W10607642	Bracket, Cooktop (Right)			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	4	W10434452	Switch, Infinite (Dual)	7		Knobs
	W11130372	Black (Left)			(Left Front)		W10844802	Stainless
	W11130379	Black (Right)		3148951	Switch, Infinite	8	W10134247	Shield, Heat
2	W10525121	Bracket, Console Mounting			(Left Rear and Right Front)	9	3400882	Screw
3		Panel, Console		3148953	Switch, Infinite (Green)	10	8272473	Cover, Upper Rear
	W11157021	Stainless			(Right Rear)	11		Electronic, Control (LCX)
			5	W10695491	Bracket, Control		W10837803	Black
			6	3196178	Screw			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge	15	W10390007	Assembly, Base Rail (Right)	28	W10627802	Switch, Door
2	W10134285	Tube, Vent				29	9757239	Rod, Door Switch
3		Panel, Side		W10390008	Assembly, Base Rail (Left)	30	W11092984	Screen, Vent
	W10162245	Black				31	W10078380	Rod, Latch
4	3400029	Nut	16	W10058460	Foot, Leveling	32	9761013	Assembly, Door Latch (Front)
5	W10658354	Seal, Door	17	3196548	Fuse, Thermal			
6	9757340	Element, Broil	18	3196172	Screw	33	3196560	Screw
7	W11111743	Element, Bake	19	W10404688	Clip, Oven Support	34	W10107820	Assembly, Door Latch (Rear)
8	W10326122	Cover, Terminal Block	20	3186034	Bracket, Service			
9	3196169	Screw	21	W10245259	Block, Terminal	35	W10910404	Counterweight
10	W10268578	Rack, Oven	22	W10289149	Back, Main	36	W11034869	Screw
11	W10341186	Assembly, Front Foot	23	W10181986	Sensor, Oven			FOLLOWING PARTS NOT ILLUSTRATED
12	W10067840	Screw	24	W11175594	Assembly, Light			
13	8054068	Retainer, Insulation	25	W10571723	Bulb, Halogen 40 Watts		W10333344	Insulation, Flue
14	W10137382	Clip, Panel	26	W10281322	Kit, Bare Wire Adapter Block		W10774939	Insulation, Wrap
							W11127325	Insulation, Back
			27	3196154	Screw			

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Top
	W10310922	Black
2	W10163951	Screw
3		Handle, Door
	W10144883	Stainless
4	9761344	Liner, Door
5	W10031790	Screw
6	9758162	Glass, Inner
7	9761357	Retainer, Insulation

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10299224	Hinge, Active (With Spring)
	W10299227	Hinge, Door (Passive)
9	W10316950	Frame, Glass
10		Trim, Side
	W10746436	Black (Left)
	W10746435	Black (Right)
11	W10327235	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12	W10278991	Insulation, Door Strip
13	W10544179	Strap, Door
14		Badge
	W10846752	Stainless
15		Glass Assembly, Outer Door
	W11170209	Stainless

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	4	W10674708	Glide, Drawer Rear	5	3196169	Screw
	W10330070	Stainless		W10674705	Glide, Drawer Front	6	3196178	Screw
2	W10462910	Bracket, Mounting Drawer						
3	W10688022	Drawer, Storage						

OPTIONAL PARTS

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	8212473	Universal Silver
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	241430	Aluminum Foil
	3191048	Glass Cleaner
	4396923	Grid, Broiler Pan and