




BOTTOM MOUNT REFRIGERATOR
Print Resistant

MODELS:

MBF1958FEZ02 (Stainless Steel)

CABINET PARTS




CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10621529	Use and Care Guide
	W11112638	Energy Guide
	W10517966	Tech Sheet
2		Cabinet (Not a Servicable Part)
3	12990504	Screw
4	W10498976	Valve, Inlet
5	W10208592	Cover, Valve
6	W10141622	Brake, Roller
7	10351006	Pin, Center Hinge
8	12990511	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	12992602	Screw
10		Cover, Hinge
	12477601AP	Grey
11	W10673840	Screw (Stainless)
12	12990521	Screw
13	12726003	Cover, Water Line
14	12992403	Screw
15		Hinge, Center
	12607103AP	Grey
16	12566606ED	Hinge, Top
17		Cover, Corner
	12587703AP	Grey

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
18	M0108107	Clamp, Tube
19		Assembly, Roller
	W10515763	Left Hand
	W10515762	Right Hand
20	W10709365	Screw
21	W10210978	Cover, Unit
22		Grille, Toe
	W10534165	Grey
23	W10485986	Guide, Waterline
24	W11046935	Assembly, Fill Tube (Includes Tubing, Fill Tube Elbow, Tube Insert and Clamp)


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	7	W11132917	Cover, Light	14	13012402	Insulation, Damper
2	W10464757	Module, Light	8	W10443023	Housing, Light	15	W10594330	Damper, Control
3	W10593588	Overlay	9	W10805744	Lamp, LED			FOLLOWING PARTS NOT ILLUSTRATED
4	W10464769	Module, Control	10	12570701V	Socket, Light			
5	W10503278	Control, Electronic	11	12806801	Insert, Damper Cover	W10422363		Harness, Refrigerator Control (Includes Thermistor)
6	C3680310V	Switch, Light	12	12990604	Screw			
			13	12806701	Cover, Damper			


FREEZER LINER & ICEMAKER PARTS



FREEZER LINER & ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	14	W10277025	Module, Light	26	13062901	Motor, Evaporator
2	A3189392	Gasket, Foam	15	13058002	Clip, Evaporator Motor	27	W10662407	Assembly, Drain Funnel
3	12002497	Gear	16	12466105	Switch, Light	28	M0500703	Seal
4	12791409SP	Thermistor	17	12932103	Guide, Fill Tube	29	B8381501	Gasket, Drain
5	W10802329	Shaft, Rack	18		Cradle, Basket	30	W10157765	Diverter, Air
6	12570701	Socket, Light		W10280608	Left Hand	31	12815301	Cover, Thermistor
7		Rail, Side		W10280613	Right Hand	32	12990501	Screw
	W10516603	Left Hand	19	W10120018	Slide, Door	33	W10793298	Assembly, Icemaker (Complete)
	W10516602	Right Hand	20	A3189394	Gasket, Bottom	34	W10445790	Cover, Icemaker
8	12990521	Screw	21		Adapter, Side	35	W10793621	Harness, Icemaker Wire
9	W10805744	Lamp, LED		W10284684	Left Hand	36	W10202524	Arm, Shut Off
10	W10277466	Foil, Housing		W10284685	Right Hand	37	W10182748	Pan, Ice
11	W10308414	Cover, Evaporator	22	13024803	Grille, Freezer Air			
12	12990101	Screw	23	13057901	Shroud, Evaporator Fan			
13		Bracket, Door	24	2169142	Blade, Fan			
	W10330991	Left Hand	25	W10150583	Grommet, Fan Motor			
	W10330993	Right Hand						


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator	5	W10371194	Bucket, Medium	9		Handle, Door
	W11254589	Stainless		W10351081	Bucket, Small		W10838129	Stainless
2		Plug, Button	6		Closure, Door	10	12990504	Screw
	12246610	Grey		12028505AP	Grey	11		Stop, Door
3	12804701SP	Door, Dairy	7	W10460893	Screw		10447114	Grey
4	12369502SP	Tray, Dairy	8		Gasket, Door	12	W10612926	Badge
				W10443310	Grey	13	12557904	Retainer, Door


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11254582	Door, Freezer Stainless	2	W10838129	Handle, Door Stainless	3	W10443312	Gasket, Door Grey
						4	W10460893	Screw


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw	17	10835903	Grommet	33	2169104	Sealer, Insulation
2	12825803	Blade, Fan	18	W10346423	Condenser	34	W10815863	Clip, Condenser
3	W10480107	Basepan	19	W10281329	Clip, Drier			FOLLOWING PARTS
4	12990511	Screw	20	W10292801	Tray, Drip			NOT ILLUSTRATED
5	W10236396	Strap, Compressor	21	12992101	Screw		978025	Valve, Access (1/4")
6	W10294014	Tube, Discharge	22	W10662565	Evaporator		978026	Valve, Access (5/16")
7	W10290745	Harness, Evaporator (Includes Heater)	23	A3189397	Gasket, Foam		978027	Valve, Access (3/8")
8	W10655367	Pan, Drain	24	W10909377	Motor, Condenser Fan		978029	Valve, Access (5/8")
9	W10622701	Screw	25	10428101	Clip, Heater		978030	Valve, Access (3/4")
10	12729127	Heater, Evaporator	26	W10679216	Harness, Unit (Includes Power Cord)		876764	Valve, Access (3/16")
11	W10216075	Strap, Bale	27	W10177049	Drier			REFRIGERANT
12	W10796752	Device, Start	28	W10879296	Compressor			CHARGE
13	W10622098	Extension, Drain	29	W10350564	Capacitor			4.25 oz (R-134A)
14	W10137529	Grommet, Condenser	30	12477202	Axle, Roller			
15	10623002	Clip, Evaporator	31	W10189184	Shroud, Condenser Fan			
16	12477102	Roller	32	2319835	Grommet, Condenser			

SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10251970	Ladder, Side	12	12531901	Track, Deli Drawer	20	W11115779	Basket, Freezer (Lower)
2	12990513	Screw	13	12227302WD	Brace, Crisper Cover	21	W10146440	Divider, Basket (Lower)
3	W10273463	Ladder, Center	14	W10231481	Trim, Crisper	22	12643602	Front, Crisper
4	W10215666	Screw	15	12724121	Pan, Crisper	23	W10802340	Shaft, Rack
5	12463608	Shelf, Stationary	16	W11115255	Basket, Freezer (Upper)	24		Gear, Spur
6	W10149389N	Lift, Bail Arm	17		Support, Pantry		W10474716	Left Hand
7	12204823N	Glass, Crisper Cover		12531001	Left Hand		W10474715	Right Hand
8	W10671240	Frame, Crisper		12531002	Right Hand	25		Mount, Gear
9	W10671238	Rail, Center Crisper	18	W10241046	Divider, Basket (Upper)		W10348259	Left Hand
10	12530805SP	Slide, Humidity Control	19	W10328331	Drawer, Pantry		W10348260	Right Hand
11	12531802	Hook, Ladder				26	W10656984	Trim, Pantry Front

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392901	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350930	White
	350939	Enamel, Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	799344	White (Uncut)
	4392900	Biscuit/Bisque

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

ACCESSORIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	31462	Cleaner, Stainless Steel

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key