


Parts Breakdown

Model DW-CN-0136 39999



Parts Breakdown

Model DW-CN-0136 39999

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
30621	Power Cord for 39999	1	70714	Cabinet Frame for 39999	19	71653	Right Small Bracket for 39999	37
70697	Base for 39999	2	70715	Top Cover for 39999	20	30747	Left Shelf Bracket for 39999	38
70646	Control Panel for 39999	3	70664	Wire Fence Left for 39999	21	30750	Right Shelf Bracket for 39999	39
70647	Bracket for Heater for 39999	4	70717	LED Lights for 39999	22	79322	Left Shelf Bracket for 39999	40
71688	Chassis of Heater for 39999	5	70718	Advertisement Light Box for 39999	23	79336	Right Shelf Bracket for 39999	41
70701	Heater Element for 39999	6	67312	Side Cover Right for 39999	24	71647	Base Feet for 39999	42
67297	Upper Hinge Front for 39999	7	67320	Side Glass for 39999	25	70686	Temperature Display for 39999	43
71658	1/9 GN Pan for 39999	8	70669	LED Lights for 39999	26	60509	Indicating Light for 39999	44
70704	Bottom Panel for 39999	9	67331	Glass Clamp for 39999	27	70688	Switch for 39999	45
70653	Front Sliding Slot for 39999	10	67310	Nut for 39999	28	71640	Temperature Thermostat for 39999	46
70654	Back Sliding Slot for 39999	11	70724	Front Door Glass for 39999	29	71662	Control 125°C for 39999	47
70707	Bottom Shelf for 39999	12	70673	Front Door Knob for 39999	30	71661	Control 150°C for 39999	48
70708	Middle Shelf for 39999	13	67308	Side Cover Left for 39999	31	70692	Socket Connector for 39999	49
70709	Upper Shelf for 39999	14	70675	Sheath of Door Knob for 39999	32	70693	Waterproof Strip for 39999	50
67327	Lamp Holder Left for 39999	15	70728	Back Door Glass for 39999	33	70694	Waterproof Strip for 39999	51
67328	Lamp Holder Right for 39999	16	70677	Back Door Knob for 39999	34	70747	Wire Fence Right for 39999	52
67329	Transparent Lamp Cover Right for 39999	17	70678	Socket for 39999	35			
67330	Transparent Lamp Cover Left for 39999	18	71652	Left Small Bracket for 39999	36			