


# Parts Breakdown

Model FW-CN-0533 21637



# Parts Breakdown

---

## Model FW-CN-0533 [21637](#)

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
27147	Plastic Plug for <a href="#">21637</a>	1	<a href="#">37129</a>	Lamp Socket for <a href="#">21637</a>	9	72750	Internal Wire for <a href="#">21637</a>	17
72739	Upper Frame for <a href="#">21637</a>	2	72745	M3 Screw for <a href="#">21637</a>	10	72751	Heat Shrinkable Tube for <a href="#">21637</a>	18
27148	On/Off Switch for <a href="#">21637</a>	3	27874	Bulb (250W Max) Clear for <a href="#">21637</a>	11	72752	M4 Screw for <a href="#">21637</a>	19
72740	Middle Frame for <a href="#">21637</a>	4	27181	*Food Tray for <a href="#">21637</a>	12	72753	Ground Screw for <a href="#">21637</a>	20
72741	Lamp Shade for <a href="#">21637</a>	5	72746	Base Tube for <a href="#">21637</a>	13	72754	Cord Grip for <a href="#">21637</a>	21
72742	Insulation Board for <a href="#">21637</a>	6	72747	Nut for <a href="#">21637</a>	14	72755	Power Cord for <a href="#">21637</a>	22
72743	Insulation Paper for <a href="#">21637</a>	7	27150	Thumb Screw for <a href="#">21637</a>	15	72756	Plug for <a href="#">21637</a>	23
72744	M5 Screw for <a href="#">21637</a>	8	72749	Plastic Pad for <a href="#">21637</a>	16			

**\* Food Tray not included**