


# Parts Breakdown

**Model RS-CN-0470** 47105



# Parts Breakdown

## Model RS-CN-0470 47105

| Item No. | Description                                 | Position | Item No. | Description                        | Position | Item No. | Description                 | Position |
|----------|---------------------------------------------|----------|----------|------------------------------------|----------|----------|-----------------------------|----------|
| 71042    | Rear Swivel Caster with Brake for 47105     | 1        | AG490    | Top Glass Shelf for 47105          | 22       | 71123    | Digital Control for 47105   | 44       |
| 79763    | Swivel Front Castor without Brake for 47105 | 2        | 71103    | Left Side Glass for 47105          | 23, 25   | 71079    | Thermostat Lid for 47105    | 45       |
| 68228    | Base for 47105                              | 3        | AG491    | Arc Glass for 47105                | 24       | 71082    | Thermostat Base for 47105   | 46       |
| AG485    | Front Cover for 47105                       | 4        | 68242    | Top LED for 47105                  | 26-1     | 68196    | Switch for 47105            | 47       |
| 68225    | Right Cover for 47105                       | 5        | AG588    | 6 LED Driver for 47105             | 26-2     | 71081    | Evaporator Motor for 47105  | 48       |
| 68226    | Left Cover for 47105                        | 6        | AG492    | Top Frame for 47105                | 27       | 68255    | Evaporator Cover for 47105  | 49       |
| 68230    | Left Blister Barrel Fixing Plate for 47105  | 7, 8     | 71153    | Shelf Holder for 47105             | 28       | 71127    | Evaporator for 47105        | 50       |
| 68232    | Evaporator Insulation for 47105             | 9        | 71164    | Left Pole Cover for 47105          | 29       | AF489    | Power Cord for 47105        | 51       |
| 68208    | Bottom LED for 47105                        | 10-1     | 71110    | Door Handle for 47105              | 30       | 68249    | Rear Frame for 47105        | 52       |
| 68222    | #4 LED Driver for 47105                     | 10-2     | AF488    | Left Doorframe for 47105           | 31       | 68250    | Back Grill for 47105        | 53       |
| AG486    | Front Glass Fixer for 47105                 | 11       | AF514    | Top Door Frame for 47105           | 32       | 71089    | Water Tray for 47105        | 54       |
| 68272    | Left Glass Fixer for 47105                  | 12       | 68244    | Door Glass for 47105               | 33       | 71133    | Power Cord Fixer for 47105  | 55       |
| 68271    | Right Glass Fixer for 47105                 | 13       | 71113    | Right Door Frame for 47105         | 34       | 71083    | Dryer Filter for 47105      | 56       |
| 68172    | Right Bottom Shelf Holder for 47105         | 14       | 71114    | Door Glide Wheel for 47105         | 35       | 77434    | Control Panel for 47105     | 57       |
| 68234    | Middle LED for 47105                        | 15-1     | 68245    | Bottom Door Frame for 47105        | 36       | 71135    | Condenser for 47105         | 58       |
| 68235    | #2 LED Driver for 47105                     | 15-2     | AG494    | Bottom Frame for 47105             | 37       | 71136    | Fan Bracket for 47105       | 59       |
| AG487    | Metal Price Tags for 47105                  | 16       | 71065    | Right Pole for 47105               | 38       | 71137    | Condenser Motor for 47105   | 60       |
| 68211    | Left Bottom Shelf Holder for 47105          | 17       | 68247    | Air In/Outlet for 47105            | 39       | 68199    | Compressor for 47105        | 61       |
| AG488    | Bottom Glass Shelf for 47105                | 18       | AF516    | Bottom Black Glass Frame for 47105 | 40       | AG495    | Top Back Frame for 47105    | 62       |
| 68175    | Right Top Shelf Holder for 47105            | 19       | 71121    | Screw Cover for 47105              | 41       | AF491    | Left Back Frame for 47105   | 63       |
| 68177    | Left Top Shelf Holder for 47105             | 20       | 71171    | Left Pole Fixer for 47105          | 42       | AF492    | Right Back Frame for 47105  | 64       |
| AG489    | Metal Shelf Support for 47105               | 21       | 71077    | Right Pole Fixer for 47105         | 43       | AG496    | Bottom Back Frame for 47105 | 65       |