


Parts Breakdown

Model VP-NL-0063-M 50005



Parts Breakdown

Model VP-NL-0063-M 50005

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
35590	Vacuum Chamber Complete for 50005	10	35258	Blind Plug 3/8" MS/VN for 50005	255	35225	Silencer ID-CL 1/8 for 50005	850
35231	Branch Pipe HFE-1 Ready for 50005	20	15716	3-Way Valve for 50005	260	35647	Protection Suction Hole SB-820-LL for 50005	860
35232	O-Ring 32x3 for 50005	30	30015	Square Hose Coupling 1/4"x6 Ext. for 50005	270	35648	Insert Plate SB-820 KL for 50005	900
35233	Filter for 50005	40	35261	Brass Hose Coupling 1/4"x8 Ext. for 50005	350	35649	Insert Plate SB-820 LL for 50005	910
35234	Adj.Screw/Soc.Head M8x30 Din916 A2 for 50005	50	15775	Micro Switch MV3003L for 50005	370	35650	Insert Plate SB-820 KK for 50005	920
27814	Hexagon Nut M8 Din934 A2 for 50005	60	27823	Hexagon Nut M3 Din934 A2 for 50005	380	35651	Vacuum Cover SB-820 Complete for 50005	1010
35236	Spring Ring M8 Din127 A2 for 50005	70	27822	Castle Washer M3 for 50005	390	35652	Sight Glass SB-820 (560x315x20) for 50005	1020
35597	Hex.Socket Head Cap Screw M5x35 Din912 A2 for 50005	80	30011	Slotted Cheese Head Screw M3x20 A2 Din84 for 50005	400	35105	Sil.Profile Lid Gasket 8mm 60°SH/25MTR for 50005	1030
15722	Vacuum Valve without Decomp.Head 32mm for 50005	90	27781	Hexagon Flangenut M6 Din6923 A2 for 50005	420	35292	Lid Locker Hook V951L7-1BP for 50005	1040
15723	Decompress Head Vacuum Valve 32mm for 50005	100	35627	Hex.Sock.Counter Head Screw M6x20 D7991 A2 for 50005	430	35293	Slotted Cheese Head Screw M3x5 A2 Din84 for 50005	1050
35600	Support Gas Cylinder SB-820 for 50005	110	35628	Hex.Sock.Counter Head Screw M6x16 D7991 A2 for 50005	450	27788	Adj.Screw/Soc.Head M6x25 Din916 A2 for 50005	1060
35242	Packing Branch Pipe Mobiles for 50005	120	27781	Hexagon Flangenut M6 Din6923 A2 for 50005	460	35295	Rod End Hinge Cover for 50005	1070
15754	Gascylinder (H-3000) for 50005	125	35272	Hex.Socket Head Cap Screw M5x8 Din912 A2 for 50005	470	35658	Wire Bush M12 (Cover SB-820) for 50005	1075
35603	Gas Cylinder 084174 / 500N for 50005	130	35273	Hinge Pin for 50005	480	27808	Adjusting Fork for 50005	1080
35604	Hexagon Screw M8x30 Din933 A2 for 50005	135	35274	Spring Collar for 50005	490	27809	Adjusting Fork Closing Pin for 50005	1090
27814	Hexagon Nut M8 Din934 A2 for 50005	140	35275	Safety Pin Hinge for 50005	500	35661	Bearing Bush PAP-0606-P10 for 50005	1100
35219	Flat Washer M8 D9021 A2 for 50005	150	35276	Spring Ring 12mm Din471 for 50005	510	35662	Hexagon Screw M12x25 Din933 A2 for 50005	1110
35247	Blindstopper + O-Ring 1/4" MS/VN for 50005	170	27827	Flat Washer M10 D9021 A2 for 50005	520	35663	Flat Washer M12 Din9021 A2 for 50005	1115
35248	Hose Coupling 1/2"x10 Ext. for 50005	180	35636	Adj.Screw/Soc.Head M10x60 Din913 A2 for 50005	530	35355	Cable Clip 1x10mm Din72571 for 50005	1120
35249	Elbow Coupling 10x1/4" for 50005	190	35637	Bush Hinge Pin SB-820 for 50005	535	35665	Tube Alu 10x1mm L=680mm SB-820 for 50005	1130
35250	Gas Nozzle Universal for 50005	200	35279	Self Locking Hexagon Nut M10 Din985 VZ for 50005	540	35666	Tube Alu 10x1mm L=370mm SB-820 for 50005	1140
35251	Hexagon Nut M8x1 Low Din439B for 50005	205	27819	Square Hose Coupling 1/8"x6 Ext. for 50005	550	35667	Tube Alu 10x1mm L=420mm for 50005	1150
35252	Gas Valve for Gas Distribute Pot for 50005	210	15751	Decompress Filter 1/2 for 50005	570	35298	Cable Gland M20x1,5 Brass for 50005	1160
35253	Closing Plug Silicone Holder for 50005	220	35282	T-Screw-in Hose Coupling 1/8"x6 Ext. for 50005	580	35299	Handle GN-565-26-192-SW 800 for 50005	1200
35254	Reducing Nipple 1/2"x3/8" for 50005	230	35203	Plug Plastic 1/8" for 50005	810	35300	Hexagon Screw M8x20 Din933 A2 for 50005	1210
35255	Distribution Block 4DVB/VP 3/8"-1/4"-4 for 50005	240	35284	Extension Piece Oil Drain for 50005	820	35301	Castle Washer Red Copper M8 for 50005	1220
35256	Air Pressure Hose Blue 10x8 for 50005	245	35285	Valve 2/2 MA-222-003-P27-SAH 24 for 50005	830	35672	Plate 495x230x5 for 50005	2000
35257	Insert Coupling Straight 1/4"x10 for 50005	250	35205	Brass Double Nipple 1/8" for 50005	840	15792	Combi-Transformer P200/460V-S24/32V for 50005	2020

Parts Breakdown

Model VP-NL-0063-M 50005

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
35304	Earth Terminal PE 4-2/3 for 50005	2030	35702	Cable Looping Sealbeam for 50005	2270	35730	Seal Mechanism SB-820-KL Top for 50005	3070
35305	End Fent for 50005	2050	35331	Cable Channel 40x40 for 50005	2280	35731	Seal Mechanism SB-820-KL Bottom for 50005	3075
35306	Fuse Clamp 2,5-2/ZSI for 50005	2060	35332	Cable Microswitch for 50005	2290	35732	Seal Mechanism SB-820-K Upper for 50005	3080
35307	Zekering Keram.5x20 2,5A Traag for 50005	2070	35333	WM01 Feed Transformer Primary for 50005	2300	35733	Seal Mechanism SB-820-KK Under for 50005	3085
15818	Fuse 5x20 4A Slow for 50005	2075	35706	WM02 Looping Mas Seal 1 2.5 for 50005	2310	15889	Sealbeam Singleseal L=500mm Complete for 50005	3100
15817	Fuse 5x20 8A Slow for 50005	2076	35334	WM05 Looping Transformer Primary for 50005	2330	35346	Seal Beam DS/1/495 for 50005	3110
15784	TMBR AB193-TAB40 2 4-4 0A for 50005	2080	35335	WM06 Mas Pump-Threading Clamp for 50005	2340	62573	Seal Beam TS/1/495 for 50005	3120
15781	TMBR AB193-TAPM Montage Sokkel for 50005	2085	35336	WM11 Pump Cable Mas-Mbs 2.5 for 50005	2350	62574	Seal Beam 8mm/1/495 for 50005	3130
35315	Double Clamp 2,5-2 for 50005	2090	35710	WC01 Control-Cable Mas Seal 1,0 for 50005	2360	15894	Sealbeam Singleseal L=800mm Complete for 50005	3140
15771	Closed Contactor AB100-C09KJ400 24Vac for 50005	2110	35711	WC03 Looping Clixon for 50005	2370	62575	Seal Beam DS/1/795 for 50005	3150
35317	Earth Terminal PE 6-10 for 50005	2130	35337	WC04 Control Transformer Fuse-Clip for 50005	2380	62576	Seal Beam TS/1/795 for 50005	3160
35318	Wire Clamp 6-2/2 AN for 50005	2140	35338	WE02 Ground Cord Machine-PE 2,5 for 50005	2390	62577	Seal Beam 8mm/1/795 for 50005	3170
35319	Rail JMV35SL 9-Hole 220mm for 50005	2150	35714	Inter Connection Double Mas100C09 for 50005	2400	35742	Seal Beam DS/1/540 for 50005	3180
35687	Wire Clamp 2.5-2/2 AN for 50005	2160	15935	Sealbag 3000800-L L=620mm for 50005	3010	62578	Seal Beam TS/1/540 for 50005	3190
35688	Clamp Connector 2.5/2 for 50005	2165	15936	Sealbag 3000800-K(KL)L=340mm for 50005	3020	62579	Seal Beam 8mm/1/540 for 50005	3200
35320	Hex.Socket Head Cap Screw M4x8 Din912 A2 for 50005	2170	15937	Sealbag 3000800-K(KK)L=375mm for 50005	3025	15891	Sealbeam Singleseal L=550mm Complete for 50005	3210
34998	Flat Washer M4 D9021 A2 for 50005	2175	35718	Pressure Beam SB-820-L for 50005	3030	27837	Hose (O2) Drago 6x13 for 50005	3290
35322	Earth Terminal M4 1x45-GR for 50005	2180	35719	Pressure Beam SB-820-K(KL) for 50005	3035	30016	Square Connect Piece 6mm for 50005	3300
35323	End Plate Wire Connector for 50005	2190	35720	Pressure Beam SB-820-K for 50005	3040	27836	Connecting Piece T-Piece 6mm for 50005	3310
35324	Seal Cord C1-07 for 50005	2200	35721	Silicon Holder SB-820-K for 50005	3045	30019	Hose Clip Klemfa 12.8x14.8mm for 50005	3320
35326	Control Cable CC1-01 for 50005	2210	35722	Silicon Holder SB-820-K-G for 50005	3046	35352	Cable Clamp 1x12mm Din7257 for 50005	3330
35327	Network-Cord CM 1-11 for 50005	2220	35723	Silicon Holder SB-820-K (KL) for 50005	3050	35353	Self Tapping Screw Pias 3.5x9.5 for 50005	3340
35696	Network-Cord CM1-03 for 50005	2221	35724	Silicon Holder SB-820-K-(KL)-G Right for 50005	3051	31554	Adj.Screw/Soc.Head M6x6 Din916 A2 for 50005	3430
35328	Feed Main Switch CM2-04 for 50005	2230	35725	Silicon Holder SB-820-K-(KL)-G Left for 50005	3052	15842	Silicone T-Profiel 40 Shore One Meter for 50005	3490
35698	Feed Main Switch CM2-02 for 50005	2231	35726	Silicon Holder SB-820-L for 50005	3055	35447	Castle Washer M10 for 50005	3560
35329	Pump Cord CM4-09 for 50005	2250	35727	Silicon Holder SB-820-L-G for 50005	3056	35755	Protect.Case Bolt Seal.Mechanism 10x1x50mm for 50005	3570
35700	Pump Cord CM4-13 for 50005	2251	35728	Sealing Mechanism SB-820-L Top for 50005	3060	35756	Spring Cutting System TPS/Seal M. SB-820 for 50005	3580
35330	Valve Cord CC2-02 for 50005	2260	35729	Sealing Mechanism SB-820-LL Bottom for 50005	3065	35372	Castle Washer M8 for 50005	3590

Parts Breakdown

Model VP-NL-0063-M 50005

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
35758	Hexagon Screw M8x60 Din933 A2 for 50005	3600	30026	Slott.Rais.Counter.Head Screw M4x12 Din7985 A2 for 50005	4180	35403	Plastic Check Nut PG 16 for 50005	9090
27787	Hexagon Screw M6x16 DIN933 A2 for 50005	3650	35381	Terminal Block 4-Pole for 50005	4200	35404	Cover Control Box for 50005	9100
35760	Spring Ring M6 Din127 A2 for 50005	3660	35382	Cover Connection Block 4-Pole for 50005	4210	35571	Cross Recessed Raised Cheese Head Screw M3.5x10 for 50005	9110
35507	Holing Block Silicon Holder HD-03 for 50005	3690	35380	Slotted Cheese Head Screw M4x12 A2 Din84 for 50005	4220	35406	Cable Gland PG16 IP65 Plastic for 50005	9120
35364	O-Ring 27x2.5 for 50005	3700	35782	Vac.Pump 063-122 230/400-3-50 E for 50005	5010	35407	Sealing Washer 0-1/4 for 50005	9130
35365	Mounting Screw Holing Block HD-03 for 50005	3740	35388	Hose Clip ABA 32-44mm for 50005	5040	35408	Reducing Ring 1/4"x1/8" for 50005	9140
35764	Spacer Sil.Holder Gas 68mm for 50005	3750	15833	PVC Suction Hose HNA-32x42mm for 50005	5050	27819	Square Hose Coupling 1/8"x6 Ext. for 50005	9150
35765	Bottom Section SB-820 for 50005	4010	35390	Pipe Nipple Half 1/2 1" for 50005	5060	34998	Flat Washer M4 D9021 A2 for 50005	9160
35368	Spring Control Box for 50005	4020	35391	Adj.Screw/Soc.Head M8x25 Din916 A2 for 50005	5070	35411	Hexagon Nut M4 Din934 A2 for 50005	9170
35369	Swivel Castor Black ST.ST. 100mm for 50005	4030	35219	Flat Washer M8 D9021 A2 for 50005	5080	35579	Vacuum Meter 40mm for 50005	9190
35370	Fixed Castor ST.ST. for 50005	4040	27814	Hexagon Nut M8 Din934 A2 for 50005	5100	35413	Elbow 1/4" Int Brass for 50005	9200
35211	Hexagon Screw M8x16 Din933 A2 for 50005	4050	35394	Control 03-Turbovac for 50005	9010	35414	Slang Pilaar 1/4"x4 BU R Norma for 50005	9210
35372	Castle Washer M8 for 50005	4060	35395	Control Turbovac Basic for 50005	9011	35415	Plug Blac R5 for 50005	9310
27814	Hexagon Nut M8 Din934 A2 for 50005	4065	35396	Packing Control + Glue-Layer for 50005	9020	35416	Plug Blac R6 for 50005	9320
35298	Cable Gland M20x1,5 Brass for 50005	4070	15780	Switch-Disconnecter Tripolar 25A Front for 50005	9040	35417	Plug Blac R10 for 50005	9330
35375	Nut M20x1.5 MS for 50005	4075	35398	Control Panel Holder Turbovac for 50005	9050	15712	Hydraulic Oil for 3-Phase Vacuum Pump (060510) for 50005	9400
35376	Cable Gland M20x1,5 Plastic for 50005	4080	35399	Upper Sticker Turbovac 03 for 50005	9051	35419	Sticker Tension + Warning for 50005	9420
35377	Lid Locker for 50005	4160	35400	Packing Cover Control + Glue-Layer for 50005	9060	27794	Sticker Machine Type for 50005	9430
27822	Castle Washer M3 for 50005	4165	30010	Brass Nut 1/4" for 50005	9070	35223	Sticker 19x38 Yellow for 50005	9440
35293	Slotted Cheese Head Screw M3x5 A2 Din84 for 50005	4170	35402	Square Hose Coupling 1/8"x4 Ext. for 50005	9080	35224	Sticker 98x65 Yellow for 50005	9450