






NEMA 5-15



037435
Housing Kit



To use the **503357** kit the bottom of your Power Pack must look like this.

WARING COMMERCIAL

Immersion Blender

WSB50 12" shaft

WSB55 14" shaft

WSB60 16" shaft



WSB65 18" shaft

WSB70 21" shaft



Date Code Location

YY|MM|DD
year|year|month|month|day|day



Catalog/Model

WSB50

WSB55

WSB60

WSB65

WSB70

WSB

WARING COMMERCIAL

314 Ella T. Grasso Ave.

Torrington, CT 06790

Tele. 1-800-269-6640

Fax 860-496-9017


www.waringcommercialproducts.com

WSB Internal and Optional Components


030443 - PCB Board Assembly



032650 - Speed Control Knob




037922 - Cord Bushing



038173 - Trigger Assembly


033666 - Cord Clamp




033654 - Screw (2 required)



038174 - Button Assembly



WSBBC - 033016
Bowl Clamp



WSB01 - 033017
Wall Hanger

Catalog/Model

WSB50

WSB55

WSB60 WSB

WSB65

WSB70

WARING
COMMERCIAL

314 Ella T. Grasso Ave.

Torrington, CT 06790

Tele. 1-800-269-6640

Fax 860-496-9017

www.waringcommercialproducts.com

Illustration#	Part#	Description
1	502955	WSB Power Pack
2	029839	Hole Plug (2 required)
2A	029905	Hole Plug
3	029840	Screw (3 required)
4	029841	Nameplate Panel
5	029842	Screw
6	029843	Hole Plug
7	029844	Screw
8	029845	Screw (3 required)
9	029846	Screw
10	029844	Screw
11	030442	Cord Set
12	030440	Housing Cover
13	032650	Speed Control Knob
14	502956	12" Shaft Assembly with Blade
15	502957	14" Shaft Assembly with Blade
16	502958	16" Shaft Assembly with Blade
17	503002	18" Shaft Assembly with Blade
18	503003	21" Shaft Assembly with Blade