
OVEN PARTS

For Models: JMW3430WB00, JMW3430WS00, JMW3430WR00, JMW3430WP00
(Black) (Stainless) (Oil Bronze) (Pro−Style)

30" MICROWAVE / WALL OVEN COMBO



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: JMW3430WB00, JMW3430WS00, JMW3430WR00, JMW3430WP00
(Black) (Stainless) (Oil Bronze) (Pro−Style)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
		Installation Instructions
	W10221384	English
	W10075750	Bi−Lingual
		Owners Manual
	W10221393	Combo
	W10233422	Microwave
		Brochure, Tips (Safe Cooking)
	9762761	English
	W10065852	French
		Tech Sheet
	W10213732	English
	W10213741	French
2	2624F043−51	Back, Main
3	3601F343−51	Baffle, Rear Lower
4	W10280327	Panel, Bottom
5	8038P035−60	Foot, Plastic
6	W10213759	Support, Air Channel
7	3401F079−45	Pan, Hidden Bake
9	W10213818	Gasket
10	W10176218	Retainer, Gasket
11	4006W217−45	Assy., Box Vent
12	8034P008−60	Screen, Smoke Elm.
13	W10286173	Switch, Micro
14	W10175989	Assembly, Light
15	8026P065−60	Tube, Vent
16	7718P033−60	Button, Plug (Thermostat)
17	W10175995	Panel, Side
18	W10175996	Retainer, Rear Insulation
19	W10175998	Pnl, Top Retainer
20	W10213792	Cover, Vent
21	7403P899−60	Switch, Hi Limit
22	W10280325	Channel, Btm Air
23	W10187003	Lens
24	W10277588	Trim, Side
25		Trim, Bottom Vent
	W10238700	Black/Oil Bronze
	W10176036	SS, Pro−Style
26		Bkt, Reinforcement
	W10277423	Left, Side
	W10277424	Right Side
27	W10186984	Cover, Rear
28	W10213755	Latch, Door
29	W10169757	Bulb, Oven
30	W10213745	Frame, Micro Sw
31	W10176018	Trim, Cntrl Panel
32	7101P426−60	Screw
33	7101P434−60	Screw
34	W10236129	Screw
35	W10277592	Switch, Oven Limit


FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

W10186989	Insulation, Wrap
W10175994	Insulation, Back

OVEN DOOR PARTS

For Models: JMW3430WB00, JMW3430WS00, JMW3430WR00, JMW3430WP00
(Black) (Stainless) (Oil Bronze) (Pro-Style)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


OVEN DOOR PARTS

For Models: JMW3430WB00, JMW3430WS00, JMW3430WR00, JMW3430WP00
(Black) (Stainless) (Oil Bronze) (Pro−Style)

Illus. No.	Part No.	DESCRIPTION
1	W10187019	Liner, Door
2		Hinge, Door
	W10176157	Black/Oil Bronze
	W10277751	SS, Pro−Style
3	W10176100	Glass, Inner
4	W10273676	Insulation, Door (Horizontal)
5	W10273591	Insulation, Door (Vertical)
6	W10176175	Bracket, Door Clip
7	W10176103	Retainer, Dr Glass
8	W10213816	Spacer, Inner Glass
9	W10176233	Bumper, Door
10	W10213806	Spacer, Inner Glass Side
11		Handle, Door
	W10186755	Black
	W10186756	Stainless
	W10186757	Oiled Bronze
	W10187014	Pro−Style
12	W10186882	Bracket, Inner Door Glass
13		Glass, Outer Door Assy.
	W10277593	Black
	W10176184	Stainless
	W10176224	Oil Bronze
	W10187006	Pro−Style
15	W10213803	Glass, Cavity
16	W10213722	Pad, Handle Foam
17	W10176126	Bracket, Handle
18	7101P426−60	Screw
19	W10277580	Insulation, Foil

INTERNAL OVEN PARTS

For Models: JMW3430WB00, JMW3430WS00, JMW3430WR00, JMW3430WP00
(Black) (Stainless) (Oil Bronze) (Pro-Style)




Illus. No.	Part No.	DESCRIPTION
1	7430P038-60	Probe, Meat
2	W10176138	Rack, Baking
3	W10277572	Rack, Roll-Out
4	W10186988	Rack, Offset
5	W10184147	Element, Broil
6	7406P322-60	Element, Bake
7	3807F678-45	Retainer, Element Bake
8	W10213812	Kit, Unity Convect
9	W10176060	Baffle, Unity Convection
10	7408P088-60	Receptacle, Meat Probe
11	3807F754-45	Support, Broil Element
12	3801F823-51	Bracket, Support (Hidden Bake)
13	7430P043-60	Probe, Sensor
14	7101P426-60	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS


For Models: JMW3430WB00, JMW3430WS00, JMW3430WR00, JMW3430WP00
(Black) (Stainless) (Oil Bronze) (Pro−Style)



Illus. No.	Part No.	DESCRIPTION
1		Assembly, Control Panel
	W10187359	Black
	W10212336	Oil Bronze
	W10212335	SS, Pro−Style
2	W10289538	Assy., UI Core
3	W10176094	Panel, Rear
4	W10273667	Blower
5	W10186997	Bracket, Cooling Fan
6	W10176092	Panel, Front
7	W10175829	Cable
8	7101P426−60	Screw
9	W10292566	Manager, Appliance
10	W10186983	Bracket, 2nd Blower
11	W10176142	Control, Power Microwave, UI

CABINET AND STIRRER PARTS

For Models: JMW3430WB00, JMW3430WS00, JMW3430WR00, JMW3430WP00
(Black) (Stainless) (Oil Bronze) (Pro-Style)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


CABINET AND STIRRER PARTS

For Models: JMW3430WB00, JMW3430WS00, JMW3430WR00, JMW3430WP00
(Black) (Stainless) (Oil Bronze) (Pro−Style)

Illus. No.	Part No.	DESCRIPTION
1	W10287989	Control, Electric
2	W10130901	Insulation, Side Left
3	W10120471	Cover, Side Left
4	W10120223	Thermostat
5		Not Serviced
6	W10287966	Noise Filter
7	W10120228	Control, Electric Converter
8		Not Serviced
9	W10131249	Screw
10	4375427	Actuator
11	4375321	Fuse
12	4375231	Block, Fuse
13	W10130897	Bracket, Support
14	W10287986	Thermostat
15	W10120113	Magnetron
16		Not Serviced
17	4375319	Spring, Lamp
18	W10287974	Housing, Lamp
19	W10287972	Lamp
20	W10287985	Thermostat
21	4375346	Switch
22	W10358241	Asm−Interlock (Includes Harness)
23	4375320	Reflector
24	4375318	Lens, Lamp
25	W10120231	Clip, Spring
26	8205692	Tranformer, Light
27		Not Serviced
		Right
		Left
28	W10128850	Asembly, Arm
31	W10287967	Motor, Turntable
33	W10120478	Hinge, Door
34		Not Serviced
35		Not Serviced
36		Not Serviced
37	W10330572	Blower Assembly
38	W10120229	Inverter
39	W10130890	Screw
40		Not Serviced
41		Not Serviced
42	W10120235	Plunger
43	8205683	Interlock
44		Not Serviced
45	8205704	Spring
46		Not Serviced
47	8205686	Support
48	W10120236	Arm
49	W10287988	Sensor, Humidity
50	4375418	Fan, Convection
51	W10120224	Heater, Convection
52	W10287967	Motor, Convection
53	W10287987	Sensor, Convection

MICROWAVE COMPARTMENT PARTS

For Models: JMW3430WB00, JMW3430WS00, JMW3430WR00, JMW3430WP00
(Black) (Stainless) (Oil Bronze) (Pro-Style)




Illus. No.	Part No.	DESCRIPTION
1		Support Rails
	W10176190	Right
	W10176189	Left
2	7101P426-60	Screw
3	W10176195	Support, Rear
4	W10186985	Guide, Stop
5	W10186986	Stop, Microwave
6	W10176196	Support, Front

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE DOOR PARTS

For Models: JMW3430WB00, JMW3430WS00, JMW3430WR00, JMW3430WP00
(Black) (Stainless) (Oil Bronze) (Pro-Style)




Illus. No.	Part No.	DESCRIPTION
1	8304588BL	Button, Plug
2	7101P426-60	Screw
3	W10288012	Door, Microwave
4	W10267047	Screw
5	W10176199	Bracket, Handle
6	W10213722	Foam, Bracket
7		Glass, Assembly
	W10176200	Black
	W10269421	Stainless
	W10269422	Oil Bronze
	W10269423	Pro-Style
8		Handle, Door
	W10186755	Black
	W10186756	Stainless
	W10186757	Oil Bronze
	W10187014	Pro-Style
9		Badge
	W10190724	Black
	W10214168	Stainless
	W10214169	Oil Bronze
	W10159578	Pro-Style

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP SUPPORT AND TURNTABLE PARTS

For Models: JMW3430WB00, JMW3430WS00, JMW3430WR00, JMW3430WP00
(Black) (Stainless) (Oil Bronze) (Pro-Style)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP SUPPORT AND TURNTABLE PARTS

For Models: JMW3430WB00, JMW3430WS00, JMW3430WR00, JMW3430WP00
(Black) (Stainless) (Oil Bronze) (Pro−Style)

Illus. No.	Part No.	DESCRIPTION
1		Bracket, Lower
	W10239156	Left
	W10239157	Right
2	W10283693	Trim, Side
3	W10284663	Trim, Bottom
5	W10176179	Bracket, Middle
6	W10176063	Retainer, Bottom
7	W10186984	Cover, Rear
8		Retainer, Side
	W10176065	Left
	W10176064	Right
9	W10175998	Cover, Top
10	W10176066	Cover, Service
11	8205676	Turntable
12	8205678	Ring
13	8205677	Drive, TT
14	W10120230	Cover, Plates
15	W10120480	Plate, Crisp
16	W10120484	Steamer
17	4452220	Rack, Convection
18	W10120486	Plate, Baking
19	W10120483	Rack
20	W10120481	Handle, Pan
21	W10120226	Heater, Grill
22	W10288008	Support, Grill

OPTIONAL PARTS

For Models: JMW3430WB00, JMW3430WS00, JMW3430WR00, JMW3430WP00
(Black) (Stainless) (Oil Bronze) (Pro−Style)

Illus. No.	Part No.	DESCRIPTION
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	72032	Black
		PAINT, SPRAY
	350930	White
	830864	Black
		ADHESIVE
	482338	Sealer, Silastic (3 oz.)
		WIRING HARNESS PARTS
	W10174376	Harness, Main
	5171P208−60	Harness, Meat Probe Jack
	W10174375	Harness, Signal Extended
	W10209123	Harness, Latch W/Meat Probe
	W10282791	Jumper, Secondary Thermal Fuse
	W10277599	Jumper, Thermal
	W10176182	Conduit, Combo
	W10174758	Harness, Communications
	4454949	Holder, Fuse
	W10017410	Fuse, Time Delay