Hobart Information Tracker Installation

You can install Hobart Information Tracker on Windows 95, 98, Windows NT 4.0. Refer to the following table for appropriate instructions and requirements.

ATTENTION: Your access code is **0817-0818F.**

Windows 95, 98, and NT 4.0

Windows 95, 98, and NT 4.0 platforms require:

- IBM PC compatible with Intel™ 80486, equivalent, or higher microprocessor.
- RAM memory of 8 MB or larger.
- Available Hard Disk space of 10 MB or larger.

To install Hobart Information Tracker:

1. INSERT the **Hobart Information Tracker CD-ROM** into your CD-ROM drive. In most situations, Windows will automatically detect and run the installation. If Windows automatically runs the installation, skip to step 5; if not, continue to step 2.
2. CLICK Start.
3. SELECT Run.
4. ENTER e**:\setup.exe** (where e: is your CD-ROM drive) and PRESS [ENTER].
5. ENTER your name, organization, and access code (located at the top of this page) and PRESS [ENTER].
6. READ and PRESS [ENTER] to accept terms of License Agreement.
7. SELECT the default directory or enter the applicable directory for your needs and PRESS [ENTER].
8. SELECT the default folder name, or TYPE a new folder name, or SELECT one from your existing folders list and PRESS [ENTER].
9. PRESS [ENTER] to complete installation.
10. Once the installation has been completed, please refer to the HIT User Manual for instructions on how to install the HIT application onto your scanner. The User Manual can be viewed and/or printed from the Programs Menu under the folder name specified during installation.

F-34604 (Feb. 2001)