



Outperform every day.™

Installation Instructions


Mirage® Drop-in Induction Warmer/Rethermalizer Gasket Installation

Purpose

This document is a supplement to the Operator's Manual. It explains how to install the gasket onto the rim of the Mirage® Drop-in Induction Warmer and Rethermalizer. Install the gasket before performing the installation procedure in the Operator's Manual.

NOTICE: Gasket installation is mandatory. Failure to install the gasket will void the warranty.

1. Turn the equipment so the bottom is facing up.
2. Set the equipment on a stable surface, such as a countertop.
3. Lubricate the gasket with a small amount of liquid dish soap or water.
4. Carefully press the groove of the gasket onto the underside edge of the rim. Take care to evenly press the gasket as you feed it onto the rim, without stretching it.



5. If needed, use a scissors to trim the gasket to the proper length.
6. Continue with the installation procedure in the Operator's Manual.



Outperform every day.™

www.vollrath.com

The Vollrath Company, L.L.C.
1236 North 18th Street
Sheboygan, WI 53081-3201 U.S.A.
Main Tel: 800.624.2051 or 920.457.4851
Main Fax: 800.752.5620 or 920.459.6573
Customer Service: 800.628.0830
Canada Customer Service: 800.695.8560

Technical Services
techservicereps@vollrathco.com
Induction Products: 800.825.6036
Countertop Warming Products: 800.354.1970
All Other Products: 800.628.0832