



## INSTALLATION AND OPERATION MANUAL

### GARLAND EFW400 FONDANT WARMER



**FOR YOUR SAFETY:**  
DO NOT STORE OR USE GASOLINE  
OR OTHER FLAMMABLE VAPORS OR  
LIQUIDS IN THE VICINITY OF  
THIS OR ANY OTHER  
APPLIANCE

**WARNING:**  
IMPROPER INSTALLATION, ADJUSTMENT,  
ALTERATION, SERVICE OR MAINTENANCE  
CAN CAUSE PROPERTY DAMAGE, INJURY,  
OR DEATH. READ THE INSTALLATION,  
OPERATING AND MAINTENANCE  
INSTRUCTIONS THOROUGHLY  
BEFORE INSTALLING OR  
SERVICING THIS EQUIPMENT

PLEASE READ ALL SECTIONS OF THIS MANUAL  
AND RETAIN FOR FUTURE REFERENCE.

THIS PRODUCT HAS BEEN CERTIFIED AS  
COMMERCIAL COOKING EQUIPMENT AND  
MUST BE INSTALLED BY PROFESSIONAL  
PERSONNEL AS SPECIFIED.

INSTALLATION AND ELECTRICAL CONNECTION  
MUST COMPLY WITH CURRENT CODES:  
IN CANADA - THE CANADIAN ELECTRICAL  
CODE PART 1 AND / OR LOCAL CODES.  
IN USA - THE NATIONAL ELECTRICAL CODE  
ANSI / NFPA - CURRENT EDITION.

ENSURE ELECTRICAL SUPPLY CONFORMS WITH  
ELECTRICAL CHARACTERISTICS SHOWN ON  
THE RATING PLATE.

Users are cautioned that maintenance and repairs must be performed by a Garland authorized service agent using genuine Garland replacement parts. Garland will have no obligation with respect to any product that has been improperly installed, adjusted, operated or not maintained in accordance with national and local codes or installation instructions provided with the product, or any product that has its serial number defaced, obliterated or removed, or which has been modified or repaired using unauthorized parts or by unauthorized service agents. For a list of authorized service agents, please refer to the Garland web site at <http://www.garland-group.com>. The information contained herein, (including design and parts specifications), may be superseded and is subject to change without notice.

GARLAND COMMERCIAL INDUSTRIES  
185 East South Street  
Freeland, Pennsylvania 18224  
Phone: (570) 636-1000  
Fax: (570) 636-3903

GARLAND COMMERCIAL RANGES, LTD.  
1177 Kamato Road, Mississauga, Ontario L4W 1X4  
CANADA  
Phone: 905-624-0260  
Fax: 905-624-5669

Enodis UK LTD.  
Swallowfield Way, Hayes, Middlesex UB3 1DQ ENGLAND  
Telephone: 081-561-0433  
Fax: 081-848-0041

# GENERAL INFORMATION

## Unpacking

Carefully remove unit from carton. Remove all packing materials, any protective material covering the stainless steel should be removed immediately after the unit is installed.

## Serial Plate Location

Electrical rating is shown on the serial plate and is readily visible on the rear of the unit next to the power supply cord inlet.

NOTE: Ensure electrical supply conforms with electrical characteristics shown on the rating plate.

## Safety

- A qualified person must make the installation in accordance with the authority having jurisdiction and local codes.
- This unit must only be operated by a qualified person. DO NOT operate without reading this manual.
- DO NOT operate this appliance unless all service and access panels are in place and fastened properly.
- DO NOT attempt to repair or replace any part of this appliance unless all main power supplies have been disconnected.

- DO NOT clean this appliance unless the power supply is disconnected.
- DO NOT immerse appliance in water.

## WARNING

To avoid serious personal injury:

- USE EXTREME CAUTION in setting up, operating and cleaning these appliances to avoid coming in contact with hot surfaces. Suitable protective clothing should be worn or proper utensils to prevent the risk of burns.
- NOTE all warning labels and markings on this appliance, which call attention to further dangers and necessary precautions.

## Wall Clearances

Back: 0  
Sides: 0

## National Code Requirements

The installation and connection should comply with current codes: In Canada - The Canadian Electrical Code Part 1 and / or local codes. In USA – The National Electrical Code ANSI / NFPA – current edition.

# OPERATING INSTRUCTIONS

This appliance has been designed to have water in the tank for even heating. Before first use it is recommended that the inside of the tank be cleaned with a detergent soaked cloth, to remove fabricating and protective oils. Rinse with clean water and dry with a clean cloth.

1. Fill the tank with water so that the level is between the minimum and maximum embossed lines on the inside wall of the tank.

2. Insert pan with a maximum depth not exceeding 4" (102mm)
3. Plug appliance into electrical outlet.
4. Turn on appliance with green switch. The appliance will heat the bath of water and maintain it at 130°F to 140°F (54° C to 60°C).

# OPERATING INSTRUCTIONS continued

NOTE: Periodic checks should be made during the operating duration to ensure that the water level does not get below the lower embossed line. Should it do so, top up with fresh water.

## MAINTENANCE AND CLEANING

### Daily Maintenance

Empty the water from the tank and clean any lime deposit with a non-metallic scouring pad. Clean with a cloth soaked in a mild detergent and hot water. Rinse with a sponge dipped in clean hot water dry with a clean cloth.

### Cleaning

Stainless steel should be cleaned using a mild detergent, a soft cloth and hot water. If it is necessary, use a non-metallic scouring pad to remove stubborn grime. Always rub in the direction of the grain in the metal to prevent scratching. Wash a small area at a time and rinse the washed area with a clean sponge dipped into a disinfectant and wipe dry with a soft clean cloth.

Use only stainless steel, wood, or plastic tools to scrape off heavy deposits. Do not use ordinary steel scrapers or knives, as particles of iron may become embedded and rust.

NEVER USE STEEL WOOL.

### Preventative Maintenance

To ensure long life, efficient and safe operation of your equipment, it is recommended that a maintenance and servicing program be performed at regular intervals, the frequency of which will vary, depending on the installation conditions and amount of usage.

Competent persons in accordance with the authority having jurisdiction must carry out all servicing and repairs.

It is essential that the instructions in this manual be strictly followed for the safe and economical operation of this equipment. If it is known or suspected that a fault exists on an appliance, then that appliance must not be used until the fault has been rectified by a competent person.

 **Garland**<sup>®</sup>